




Operating Manual
Network Analyzer
PQ-Box 50
Power-Quality Evaluation Software





Note:

Please note that this operating manual cannot describe the latest version of the device in all cases. For example, if you download a more recent firmware version from the internet, the following description may no longer be accurate in every point.

In this case, either contact us directly or refer to the most recent version of the operating manual, available on our website (www.a-eberle.de).

A. Eberle GmbH & Co. KG

Frankenstraße 160

D-90461 Nuernberg

Tel.: 0911 / 62 81 08 0

Fax: 0911 / 62 81 08 96

E-Mail: info@a-eberle.de

Internet: www.a-eberle.de

A.-Eberle GmbH & Co. KG cannot be held liable for any damage or losses, resulting from printing errors or changes to this operating manual.

Furthermore, **A. Eberle GmbH & Co. KG** does not assume responsibility for any damage or losses resulting from defective devices or from devices altered by the user.

Copyright 2019 by A. Eberle GmbH & Co. KG

All rights reserved.

Table of Contents

1.	User Guidance.....	6
1.1	Target group	6
1.2	Warnings.....	6
1.3	Tips.....	6
1.4	Other Symbols	7
1.5	Applicable documentation	7
1.6	Keeping	7
1.7	Updated documentation	7
2.	Safety Instructions	8
2.1	Safety instructions	8
2.2	Meaning of the symbols used on the device.....	9
3.	Scope of Delivery/Order Codes PQ-Box 50	10
3.1	Scope of Delivery	10
3.2	Order Codes.....	10
3.3	Technical data.....	12
4.	Accessories for current measurement	14
4.1.1	Rogowski current clamps.....	14
4.1.2	Current clamps	15
4.1.3	Accessories for current measurement	17
5.	Intended use	18
6.	Description	18
7.	Hardware PQ-Box 50	19
7.1	PQ-Box 50 Hardware	19
7.1.1	Overview PQ-Box 50.....	19
7.2	Accumulator	21
8.	Network connection PQ-Box 50	22
8.1.1	Direct connection to a 3-phase low voltage network	22
8.2	Connection to a single-phase low voltage network	23
8.3	Connection to an isolated IT network	24
8.4	Connection to secondary transformer	25
8.5	Special circuit types	26
8.6	Starting a measurement.....	27
8.7	Memory management.....	27
8.8	Delete device memory.....	27
8.9	WLAN PQ-Box 50	27

9.	PQ-Box App	28
9.1	Connection PQ box.....	28
9.2	Online measurement data PQ-Box.....	28
9.2.1	Numerical online measurement data.....	29
9.2.2	Graphical online measurement data	30
9.2.3	Setup - Parameterization PQ-Box.....	31
10.	Evaluation software WinPQ mobile	32
10.1	SW – Installation / Removal / Update	32
10.2	Software Wizard	34
10.3	WinPQ mobile start screen.....	35
10.4	General Software Settings.....	36
10.4.1	TCP-IP Settings in WinPQ mobil.....	41
10.5	Transferring measurement data from the PQ-Box to the PC.....	42
10.5.1	Data folder in Windows Explorer	43
10.5.2	Transferring measurement data while a measurement is in progress	44
10.6	Evaluation of Measurement Data.....	46
10.6.1	Change the measurement data directory	47
10.6.2	Standard evaluation for EN50160 and IEC61000-2-2	49
10.6.3	Bar chart of the Harmonics and Interharmonics.....	54
10.6.4	D-A-CH-CZ report.....	56
10.6.5	Level-time diagrams of the long-term data.....	57
10.6.6	Oscilloscope recordings	64
10.6.7	½ periode rms RMS Recorder	66
10.6.8	Ripple Control Signal Recorder	67
10.6.9	PQ Events.....	68
10.6.10	Data export – Interval data.....	70
10.6.11	Additional functions	73
11.	PQ-Box Limits and Settings	76
11.1	Setup - Basic Settings.....	77
11.2	Setup – EN50160 / IEC61000-2-2 / IEC61000-2-4 Limits	84
11.3	Oscilloscope trigger settings.....	86
11.4	½ period rms Recorder	88
11.5	Automatic Trigger.....	89
11.6	Ripple control signal analysis.....	90
11.7	Scheduled Operation	91
11.8	PQ-Box 50 Firmware Update	92
11.9	PQ-Box License Update	93

12.	Data Converter.....	93
12.1	Change VT and CT ratio	93
12.2	Merging partial measurements into a combined measurement	94
13.	Online Analysis: PQ-Box & PC	95
13.1	Online - Oscilloscope Image	95
13.2	Online – FFT – 10kHz	96
13.3	Online - Harmonics	98
13.4	Online - Interharmonics	99
13.5	Online – Direction of the Harmonics	100
13.6	Harmonic power and phase angle	102
13.7	Online Level-Time Diagram	103
13.8	Online - Measurement Value Details	104
13.9	Online - Phasor Diagram.....	105
13.10	Power Triangle	106
13.11	Online Status PQ-Box.....	107
14.	Measurement Data – PQ-Box 50	108
14.1	Measured quantities.....	108
14.2	PQ-Box Measurement Procedure / Formulas	108
15.	Maintenance/Cleaning	117
16.	Calibration	117
17.	Disposal	117
18.	Product Warranty	118

1. User Guidance


1.1 Target group

The User Manual is intended for skilled technicians as well trained and certified operators. The contents of this User Manual must be accessible to people tasked with the installation and operation of the system.

1.2 Warnings


Structure of the warnings


Warnings are structured as follows:


 SIGNAL WORD	Nature and source of the danger. Consequences of non-compliance. ● Actions to avoid the danger.
--	--

Types of warnings

Warnings are distinguished by the type of danger they are warning against:

 DANGER!	Warns of imminent danger that can result in death or serious injuries if not avoided.
--	---

 WARNING!	Warns of a potentially dangerous situation that can result in death or serious injuries when not avoided.
---	---

 CAUTION!	Warns of a potentially dangerous situation that can result in fairly serious or minor injuries when not avoided.
---	--

NOTICE:	Warns of a potentially dangerous situation that if not avoided could result in material or environmental damage.
----------------	--

1.3 Tips



Tips on the appropriate device use and recommendations.

1.4 Other Symbols

Instructions

Structure of instructions:

👉 Guidance for an action.

→ Indication of an outcome, if necessary.

Lists

Structure of unnumbered lists:

- List level 1
 - List level 2

Structure of numbered lists:

- 1) List level 1
- 2) List level 1
 1. List level 2
 2. List level 2

1.5 Applicable documentation

For the safe and correct use of the product, observe the additional documentation that is delivered with the system as well as the relevant standards and laws.

1.6 Keeping















Keep the user manual, including the supplied documentation, readily accessible near the system.

1.7 Updated documentation

The most recent versions of the documents can be obtained at <https://www.a-eberle.de/de/downloads>.

2. Safety Instructions

2.1 Safety instructions

-  Follow the operating instructions.
-  Keep the operating instructions with the device.
-  Ensure that the device is operated only in a perfect condition.
-  Never open the device.
-  When opening the battery compartment, disconnect the power supply.
-  Ensure that only qualified personnel operate the device.
-  Connect the device only as specified.
-  Ensure that the device is operated only in the original condition.
-  Connect the device only with recommended accessories.
-  Ensure that the device is not operated outside the design limits. (See the technical data)
-  Ensure that the original accessories are not operated outside the design limits.
-  For measurements in short circuit resistant systems, ensure that voltage taps with integrated fuses are used.
-  Do not use the device in environments where explosive gases, dust or fumes occur.
-  Clean the device only with commercially available cleaning agents.

DANGER!

Danger to life due to electric shock!

If the device is used in a way not specified by the equipment producer, the device protection will be impaired.

 Observe safety instructions

2.2 Meaning of the symbols used on the device



Nature and source of the danger! Read the safety instructions inside the manual!



Voltage ground



USB-interface



CE marking guarantees compliance with the European directives and regulations regarding EMC



The unit is fully protected by double or reinforced insulation.

IP65

6X = Protection against dust

Protection against water **X5** = Protection against water jets from any angle



AC voltage



DC voltage

CAT IV

Category IV

3. Scope of Delivery/Order Codes PQ-Box 50

3.1 Scope of Delivery

- PQ-Box 50
- User Manual
- Case
- 3 red dolphin clips, 1 blue dolphin clip, 1 green dolphin clip
- 3 high-load fuses integrated in voltage leads
- USB cable
- 2 voltage leads for integrated wide range power supply with 2 x 4 mm safety plugs and integrated high-load fuses

3.2 Order Codes

The following device options are available for the PQ-Box 150 device and can be activated at any time via a license code.

▶ **Optional “Ripple control recorder” (R1)**

- Used for triggering and recording ripple control signals for voltages and currents.

The PQ-50 Box is available in different versions:

▶ **PQ-Box 50 basic (B0)**

The device is suitable for performance analyses for energy audits according to ISO 50001, as a data logger for troubleshooting and for online measurements.

▶ **PQ-Box 50 light (B1)**

This version is equipped with manual trigger option for oscilloscope and ½ cycle RMS records. Standard evaluations according to EN50160, IEC61000-2-2/2-4 for public and industrial power systems are automatically generated.

▶ **PQ-Box 50 expert (B2)**

This version is additionally equipped with comprehensive trigger functions for oscilloscope and ½ cycle RMS records.



With a licence code, the PQ-Box 50 can be upgraded with ripple control recorder, B1 light or B2 expert.

Performance			
PQ-Box 50	basic (B0)	light (B1)	expert (B2)
Statistic EN50160/IEC 61000-2-2/IEC 61000-2-4		x	x
PQ-events		x	x
Recording free interval (1sec...30min):			
Voltage: min. max. average	x	x	x
Current: min. max. average	x	x	x
Power: P, Q, S, PF, cos phi, sin phi, tan phi	x	x	x
Distortion power D	x	x	x
Energy: P, Q, P+, P-, Q+, Q-	x	x	x
Flicker according IEC61000-4-15 (2010) (Pst, Plt, Ps5)	x	x	x
Unbalanced voltage, current	x	x	x
Voltage harmonics		up to 50 th	up to 50 th
Voltage harmonics extreme values 200ms			x
Current harmonics		up to 50 th	up to 50 th
Current harmonics extreme values 200ms			x
Phase angle of current and voltage harmonics			x
Real, apparent and reactive power of harmonics			x
THD voltage, current; PWhd, PHC	x	x	x
Inter harmonics – voltage, current			DC to 10 kHz
Ripple control signal		x	x
Frequency: min. max. average	x	x	
Power / Energy Interval			
10/15/30 min interval – Voltage, P, Q, S, D, cos phi, sin phi ...	x	x	x
Online mode:			
Oscilloscope recorder	x	x	x
½ cycle RMS recorder		x	x
Voltage & current harmonics, inter harmonics		x	x
FFT spectrum (U, I)			DC to 10kHz
Direction of harmonics			x
Trigger options:			
½ cycle RMS recorder (U, I, P, Q, S, frequency)			x
Oscilloscope recorder (U, I)			x
Phase shift trigger, wave shape trigger			x
Interval-trigger			x
Automatic trigger			x



With a licence code, the PQ-Box 50 can be upgraded from lower version to a higher version.

3.3 Technical data

PQ Box 50 (4U/4I)	
4 voltage inputs (AC/DC): Maximum input voltage:	L1, L2, L3, N, E; DC 848V = AC 1039V/600V ~ 1.2 MΩ impedance
4 current inputs (AC/DC):	1000 mV input for mini clamp and 330 mV for Rogowski coils 15 kΩ impedance
Sampling rate:	20.48 kHz at 50 Hz/60 Hz
Automatic synchronization to fundamental oscillation:	45 Hz to 65 Hz
Measurement intervals:	Freely adjustable from 1 s to 30 min + 10/15/30 min
Data memory:	1 GB
Interfaces:	WLAN/WiFi, USB
Time synchronization:	NTP with WLAN
Dimensions:	220 x 110 x 40 mm
Mass:	1 kg
Degree of protection:	IP65
IEC 61000-4-30 Ed.3:	Class A
Accuracy:	< 0,1 %
Insulation class:	CAT IV / 600 V
Insulation test	Impulse voltage = 12,8 kV 5 sec = 7,4 kV rms
A/D converter:	16 Bit
Climate/temperature proof:	Function: -20°50°C Storage: -30°80°C
Power supply:	AC 100 V...440 V ~ OVC IV 50/60Hz; 180..80mA oder DC 100 V...250 V =; 105...35mA 440V CAT IV

EMC	
CE- conformity	
<ul style="list-style-type: none"> Interference immunity <ul style="list-style-type: none"> EN 61326 EN 61000-6-2 Emitted interference <ul style="list-style-type: none"> EN 61326 EN 61000-6-4 	
ESD	
<ul style="list-style-type: none"> IEC 61000-4-2 IEC 60 255-22-2 	8 kV / 16 kV
Electromagnetic fields	
<ul style="list-style-type: none"> IEC 61000-4-3 IEC 60 255-22-3 	10 V/m
Burst	
<ul style="list-style-type: none"> IEC 61000-4-4 IEC 60 255-22-4 	4 kV/2 kV
Surge	
<ul style="list-style-type: none"> IEC 61000-4-5 	2 kV/1 kV
HF conducted disturbances	
<ul style="list-style-type: none"> IEC 61000-4-6 	10 V, 150 kHz ... 80 MHz
Voltage dips	
<ul style="list-style-type: none"> IEC 61000-4-11 	100 % 1 min
<ul style="list-style-type: none"> Housing at a distance of 10 m AC supply connection at a distance of 10 m 	30...230 MHz, 40 dB 230...1000 MHz, 47 dB 0.15...0.5 MHz, 79 dB 0.5...5 MHz, 73 dB 5...30 MHz, 73 dB

Measurement quantity	Error limits according IEC 61000-4-30, Class A
Fundamental oscillation: r.m.s.	$\pm 0.1\%$ of U_{din} over 10% ~ 150% of U_{din}
Fundamental oscillation: Phase	$\pm 0.15^\circ$ over 50% ~ 150% of U_{din} over $f_{nom} \pm 15\%$
2nd ... 50th harmonic	$\pm 5\%$ of display over $U_m = 1\% \sim 16\%$ of U_{din} $\pm 0.05\%$ of U_{din} over $U_m < 1\%$ of U_{din}
2nd 49th interharmonic	$\pm 5\%$ of display over $U_m = 1\% \sim 16\%$ of U_{din} $\pm 0.05\%$ of U_{din} over $U_m < 1\%$ of U_{din}
Frequency	$\pm 5\text{mHz}$ over $f_{nom} \pm 15\%$ ($f_{nom} = 50\text{ Hz} / 60\text{ Hz}$)
Flicker, Pst, Plt	$\pm 5\%$ of display over 0.02% ~ 20% of $\Delta U / U$
Dip residual voltage	$\pm 0.2\%$ of U_{din} over 10% ~ 100% of U_{din}
Dip duration	$\pm 20\text{ ms}$ over 10% ~ 100% of U_{din}
Swell residual voltage	$\pm 0.2\%$ of U_{din} over 100% ~ 150% of U_{din}
Swell duration	$\pm 20\text{ ms}$ over 100% ~ 150% of U_{din}
Interruption duration	$\pm 20\text{ ms}$ over 1% ~ 100% of U_{din}
Voltage asymmetry	$\pm 0.15\%$ over 1% ~ 5% of display
Ripple control voltage	$\pm 5\%$ of display over $U_m = 3\% \sim 15\%$ of U_{din} $\pm 0.15\%$ of U_{din} over $U_m = 1\% \sim 3\%$ of U_{din}

4. Accessories for current measurement

- Standard accessories are automatically recognized by the meter.
- The conversion factor is automatically adjusted for the connected accessory.

4.1.1 Rogowski current clamps

- ▶ **Rogowski current clamp 4~: Ident-No. 111.7001**
- ▶ **Rogowski current clamp 4~: Ident-No. 111.7006**

Model 111.7001/6

Model	111.7001 Pro Flex 3000 4~	111.7006 Pro Flex 6000 4~
Current range	3,000 A AC RMS	6,000 A AC RMS
Measurement range	0-3300 A AC RMS	0-6,600 A AC RMS
Output voltage	85 mV / 1000 A	42.5 mV / 1000 A
Frequency range	1 Hz to 20 kHz	10 Hz to 20 kHz
Isolation voltage type	600 V AC / DC CAT IV	600 V AC / DC CAT IV
Accuracy (20 °; 50 Hz)	<50 A/0.1 % of the full scale value 50-3000 A/1.5 % of the measured value	<100 A/0.1 % of the full scale value 100-6000 A/1.5 % of the measured value
Angle error (45-65 Hz)	<50 A/2.5 ° 50-3000 A/1 °	<100 A/2.5 ° 100-6000 A/1 °
Position accuracy	<50 A/0.2 % of the full scale value 50-3000 A/1.5% of the measured value	<100 A/0.1 % of the full scale value 100-6000 A/1.5% of the measured value
Long Rogowski coils	610 mm	910mm
Diameter clamp head	9,9mm	9,9mm

- ▶ **Mini- Rogowski current clamp 4~: Ident-No. 111.7085**

Current range: 500A RMS; Accuracy: 1%

Rogowski clamp length = 220mm;

Diameter = 70mm; Rogowski clamp head = 6mm

Frequency range: 10Hz to 50kHz

4.1.2 Current clamps

The MU-metal clamp is especially applicable for small current measurements on secondary transformers in medium- and high-voltage networks. High accuracy and small angle errors are combined.

▶ **Mu-Metal Mini-Current clamps 3~: Ident-No. 111.7003**

Current range: 10mA to 20A

Frequency range: 40Hz to 20kHz

▶ **Mu-Metal Mini-Current clamps 4~: Ident-No. 111.7015**

Current range: 10mA to 20A/200A AC RMS (two ranges)

Frequency range: 40Hz to 20kHz

Model 111.7015

Measurement range	20 A measurement range	200A measurement range
Current range	20 A AC RMS	200 A AC RMS
Measurement range	100 mA to 20 A RMS	1 A to 200 A RMS
Output voltage	10 mV/A	1 mV/A
Frequency range	40 Hz to 20 kHz	40 Hz to 20 kHz
Isolation voltage type	600 V AC	600 V AC
Accuracy	100 mA- 10 A/1.5 % of the measured value 10-20 A/1 % of the measured value >20 A/1% of the measured value	10-40 A/<2 % of the measured value 40-100 A/<1.5 % of the measured value 100-200 A/<1 % of the measured value
Angle error	100 mA- 10 A/2 ° 10-20 A/2° >20 A/2°	10-40 A/<2 ° 40-100 A/<1.5 ° 100-200 A/<1 °



200 A Measurement range (111.7015)



Adjustment of the power converter factor to x10. For the clamp with two ranges the automatic factor detection of the PQ-Box does not work for the second.

▶ **Mu-Metal Mini-Current clamp 0...5A 1~: Ident-No. 111.7043**

Current range: 5mA to 5A AC RMS

Frequency range: 40Hz to 20kHz

Free current adapter set necessary

▶ **AC/DC Current clamp 1~: Ident-No. 111.7020**

AC/DC hall sensor clamp. Set with power supply and 2 pcs. 4mm connectors

Current range 60A/600A (two ranges)

Model 111.7020

Measurement range	AC/DC 60 A	AC/DC 600 A
Current range	60 A DC / 40A AC RMS	600 A DC / 400A AC RMS
Measurement range	200 mA to 60 A RMS	600 A RMS
Output voltage	10 mV/A	1 mV/A
Frequency range	DC to 10 kHz	DC to 10 kHz
Isolation voltage type		
Accuracy	0.5-40 A/<1.5 % +5 mV 40-60 A/1.5 %	0.5-100 A/<1.5 % +1 mV 100-400 A/<2 % 400-600 A(DC only)/<2.5 %
Angle error	10-20 A/<3 ° 20-40 A/<2.2 °	10-300 A/<2.2 ° 300-400 A/<1.5 °



600 A Measurement range (AC/DC)



Adjustment of the power converter factor to x10

4.1.3 Accessories for current measurement

▶ **Free Adapter set for connecting 4 clamps: Ident-No.: 111.7004**

Adapter set for connecting 4 clamps or shunt with 4mm connectors. 2m length

⚠ CAUTION!	Damage to the device from external current clamps 🖐 Do not use clamps with A or mA output 🖐 Avoid input voltages at the current inputs greater than 30 V
-------------------	---



Power conversion factor

Current conversion correction factor; the default is 1 A/10 mV

Example:

If you use a current clamp with a 500 A to 500 mV range, it is necessary to change the CT ratio in the setup of the device to “10x”.

▶ **Current clamp cable extension: Ident-No.: 111.7025**



Cable extension 5 m for current clamps or Rogowski coils.

▶ **Current-shunt 2A: Ident-No.: 111.7055**

Measurement of AC- and DC-currents. Current range = 2A / 200mV output signal

5. Intended use

The product is exclusively for the measurement and evaluation of voltages and currents. The current inputs are mV-inputs.

-  Observe safety instructions
-  Ensure that the device is not operated above the rated data

6. Description

The Network Analyzer PQ-Box 50 is suitable for analysis in low, medium and high-voltage networks. It meets all the requirements of the measurement equipment standard IEC61000-4-30 Ed. 3 class A.


Functions:

- Voltage quality measurements according to EN50160, IEC61000-2-2 and IEC61000-2-4 for low and medium voltage networks
- Fault recorder functions
- Load analyses; energy measurements
- Ripple control signal analysis
- Transient analysis

7. Hardware PQ-Box 50

7.1 PQ-Box 50 Hardware

7.1.1 Overview PQ-Box 50



1) 5 voltage leads fix connected:

- L1 (red - L1)
- L2 (red - L2)
- L3 (red - L3)
- N (blue - N)
- Earth (green - E)

The housing cover can be opened by the user.
Here is a battery pack.
This can be exchanged by the user if necessary.



DANGER!

Danger to life due to electric shock!

The maximum voltage of the blade (green) must not exceed the requirement of 600V against earth

👉 Ensure that the device is not operated above the rated data



CAUTION!

Damage to measurement voltage with overvoltage

👉 Connect device to maximum DC voltage of 565V AC / 800V DC L-N.

👉 Connect device to maximum AC voltage of 980V AC / 1380V DC L-L.

2) Current clamp connection (Amphenol plug 7-pole)

3) The PQ-Box 50 is equipped with an internal extremely robust wide-range power supply. The power supply is designed for the high immunity of 300V CAT IV and complies with the protection class IP65.

The PQ box can be supplied with energy directly at the measuring point via this adapter and does not require a separate socket.

The following voltage ranges for the mains supply are possible: 88 V ... 500 V AC or 100V ... 300V DC

High-voltage fuses are installed in both measuring lines. These can be exchanged by the user.



CAUTION!

Damage to power supply due to under- or overvoltage

👉 Only power the device between 88V and 500V AC.

👉 Only supply power between 100 and 300 V DC.

👉 Do not supply the device directly from strongly disturbed voltages. (eg. at the frequency inverter output / Caution high clock frequencies can destroy the internal power supply)




DANGER!

Danger to life due to electric shock!

Only fuse 6.3mm x 32mm, 3 A F, with a breaking capacity of 50kA/600V may be used in the fuse carrier. Only fuses with the identical data may be used.

👉 Make sure that the fuses used comply with the specifications.

Front panel picture – keypad



▶ LED display

Measurements are started and stopped via a "Start / Stop" button. If a recording has been started, this will be indicated by a flashing recorder LED.

Many measurements can be recorded one after the other without having to read the instrument beforehand. A glowing WLAN icon indicates if this interface is active and accessible.

7.2 Accumulator

The PQ Box 50 is equipped with a lithium-ion battery and intelligent charging electronic.

The aim is to achieve a long battery life time. At 80% capacity, the PQ-Box can run approximately 2 hours without mains supply.

The Li-ion battery is first charged to 100% when the threshold (75%) is reached. This has a very positive effect on the total life time of the batteries.

Aging: At high temperature and the battery is full, the cell oxidation developed particularly rapidly. This condition may occur, f. e. in notebooks when the battery is fully charged and at the same time, the device is in operation. The optimal charge level is between 50% and 80% during storage.

- Charging stops when exceeding a battery temperature of 50 ° C
- Start charging only when the battery temperature is less than 45 ° C
- Warning Battery capacity below 7%
- PQ-Box shutdown when battery capacity <5%




We recommend storing the battery of the PQ-Box at 15 ° C with a charge of 60% - this is a compromise between accelerated aging and self-discharge. The battery of the PQ-Box should be recharged to approximately 55-75% every six months, due to the natural self-discharge, in order to ensure a long-term service life.

8. Network connection PQ-Box 50

8.1.1 Direct connection to a 3-phase low voltage network

Connection in a 3-phase 4-wire AC network




Voltage connection

- 👉 Ensure that voltage measurement cable PE is connected for every measurement.
- 👉 If no PE connection is available, connect E and N together.
- 👉 Ensure that switching (4-wire) is selected. (Setting via display or software)

8.2 Connection to a single-phase low voltage network

Connection for single-phase measurements




Voltage connection

- 👉 Ensure that voltage measurement cable E is connected for every measurement.
- 👉 If no PE connection is available, connect E and N together.
- 👉 Ensure that switching “1-wire system” is selected. (Setting via PQ-Box App or software)

☒ 1-wire System

- 👉 Not necessary to connect phases L2 and L3 for voltage and currents in single phase measurement.

8.3 Connection to an isolated IT network



Connections

- ✎ Connect terminals E and N together and connect it to a ground potential.
- ✎ Ensure that switching (3-wire) is selected. (Setting via display or software)




The input impedance of a measuring input is 1,2 mega ohms.







If the high-resistance ground connection is not desired, it is also possible to interconnect the terminals E and N and to hang open. (No connection to any ground)

In 3-wire connection the 4th voltage channel and the 4th current channel will be calculated from the device. (Voltage Neutral to Ground and current of the star point)

8.4 Connection to secondary transformer



Connections


-  Ensure that voltage measurement cable E is connected for every measurement.
-  If no PE connection is available, connect E and N together.
-  Ensure that switching (3-wire) is selected. (Setting via display or software)
-  Set the voltage transformer ratio
-  Enter the nominal conductor-conductor voltage
-  Set the current transformer ratio



In 3-wire connection the 4th voltage channel and the 4th current channel will be calculated from the device. (Voltage Neutral to Ground and current of the star point)

8.5 Special circuit types

Configurations such as a V connection or aron connection can be parameterized.




- V connection (parameterization through the evaluation software or device setup)
- Aron connection (parameterization through the evaluation software or device setup)

Isolated networks

Connections

- ✎ Connect voltage measurement conductors E and N to ground
- ✎ If this is not desired in the plant due to isolation monitoring, the E and N connections can be connected together and remain free without connection.
- ✎ Ensure that switching (3-wire) is selected.
- ✎ Set the voltage transformer ratio
- ✎ Enter the nominal conductor-conductor voltage
- ✎ Set the current transformer ratio

8.6 Starting a measurement



Press the key to stop or start measuring.

- Recording "On" is indicated by green flashing light "Record"
- Recording stopped - LED record is off
- Memory PQ-Box 50 full - LED record and status light permanently.

The recording is stopped.

- Attempt to start a measurement when the memory is full - Status LED changes to orange and Recorder LED flashes 2 x at a time.

8.7 Memory management

So that the recorder data does not fill the whole memory when a too sensitive or incorrect trigger level is set and thus the long-term recording is stopped, at the start of the measurement the PQ Box 50 reserves a maximum size of the free space for all fault records.

8.8 Delete device memory

Using a key combination at the start of the device, it is possible to completely erase the device memory.

- Establish power supply to the PQ-Box 50
- Orange LED lights up
- Now press the start button until orange LED and green LED flash together
- If the start button is pressed within 3 seconds, the device memory will be erased and the PQ Box 50 will start. If the start button is not pressed, PQ box will start without clearing the memory.

8.9 WLAN PQ-Box 50

The name of the WLAN router shown in the network for PQ Box 50 is: „PQBoxAP_*serial number*“
For connection you have to enter the WPA2 Key on your PC or mobile phone. The current WPA2-Key is displayed on the WLAN interface setup screen as shown above.



9. PQ-Box App




Via an app for Android and IOS operating systems, all PQ boxes with integrated WLAN/Wifi interface can be operated wirelessly. The app is available for free download in the Apple App Store as well as in the Google Play Store.


A variety of online screens are available. All measuring devices can also be easily parameterized, e.g. via a smartphone. Verbindungsaufnahme PQ-Box

9.1 Connection PQ box

The PQ-Box acts as a WLAN router. SSID and password for a WPA2 connection can be found on the nameplate of the network analyzer. (Example: "1743-203")




9.2 Online measurement data PQ-Box




► Start screen - Dashboard

Information about:


- Free device memory PQ-Box
- Battery status
- Duration of current measurement
- Voltage (V) L1, L2, L3
- Current (A) L1, L2, L3




9.2.1 Numerical online measurement data




selection screen
online features




- Voltage
- Current
- Active power with sign of direction
- Phase angle phi of the fundamental oscillation (U,I)
- AUX - Input signal AUX input (PQ-Box 200/300 only)
- Mains frequency



- Apparent power
- Collective reactive power
- Active power with sign of direction
- Distortion reactive power
- Power factor (P/S)
- Cos phi (fundamental)



- THD Voltage (%)
- THD Current (%)
- Interlinked voltages (L12; L23; L31)
- Active energy (kWh)
- Blind energy (kVAr)




► Number of triggered events

(number of records stored in the device / number of recorded records in the buffer)


- Number of oscilloscope images
- Number of effective value recorders (1/2 periods)
- Number of ripple control recorders (option R1)
- Number of Power Quality Event of the set standard template
- Number of transient recorders (PQ Box 200/300 only)

9.2.2 Graphical online measurement data





▶ phase diagram

Individual phases of voltage and current can be switched on or off in the display.



▶ Oscilloscope screen

Individual phases of voltage and current can be switched on or off in the display.



▶ Voltage harmonics


The grey bar shows the maximum value that occurred during the communication to the PQ-Box App.

▶ Current harmonics


Switching between the voltage and current harmonics display is possible via the legend..



The bar chart can be moved to the left up to the 50th harmonic..



9.2.3 Setup - Parameterization PQ-Box



- **Measuring interval**
freely adjustable: 1s to 30min (basic setting interval = 600sec)
Settings < 1 min should only be used for short measurements.
- **Nominal voltage** refers to the contractually agreed conductor-conductor voltage. All recorders refer to this value as a percentage.


Network type: Select between 1~; 3~ and 4~ conductor network.

In a 1 phase network, only the input channels L1, N and earth are evaluated.

In a 3-conductor network, all evaluations of the standard reports are calculated from the conductor-conductor voltages.


In a 4 conductor network all evaluations of the standard reports from the conductor-earth voltages are determined.

Further circuit types are: V-circuit for two voltage transformers, delta high leg and split-phase network.



▶ Transducer settings

- Voltage transducer corresponds to the ratio between primary and secondary voltage
- Current transducer corresponds to the ratio between primary and secondary current



▶ Information of the PQ-Box

- Battery status; date, time; connected current clamps
- Serial number, firmware version
- Activated licenses of the PQ-Box

10. Evaluation software WinPQ mobile

The evaluation software WinPQ mobile supports the **PQ-Box 50, PQ-Box 100, PQ-Box 150, PQ-Box 200 and PQ Box 300** portable network analyzers.

It was developed in collaboration with power supply companies with the goal of creating an easy-to-use and adaptable solution for the evaluation of power quality parameters in energy distribution networks.

The network analyzer is suitable for network analyses in low, medium and high voltage networks.

The purpose of the program is to process the stored power quality measurement data and fault records for the viewer and display them on the PC screen in an appropriate manner. To this end, the program provides tools for the efficient selection of stored data and a set of graphical and tabular presentations of the parameters of power quality according to European standard **EN50160, IEC61000-2-2 or the standard for industrial networks IEC61000-2-4**.

- ✓ Automatic reporting according to the compatibility levels of EN50160, IEC61000-2-2 or IEC61000-2-4.
- ✓ Information about faults in the network by means of fault records
- ✓ Management of many measurements
- ✓ Data acquisition of long-term data and events
- ✓ Statistical long-term analyses
- ✓ Correlation of events and different measurement data
- ✓ User-friendly, user-oriented evaluation

10.1 SW – Installation / Removal / Update

System Requirements:

Operating system: Microsoft Windows 7 (32-bit & 64-bit)


Microsoft Windows 8

Microsoft Windows 10

Memory, at least 2 GB

The WinPQ mobile software is available free of charge in 32-bit and 64-bit versions.

Installation of the evaluation software:


To start the installation of the evaluation software, place the installation CD in your CD-ROM drive. If the Autostart function is activated, the installation program starts automatically. Otherwise, go to the root directory of your CD-ROM drive and start the program by double-clicking the file  SETUP.EXE .

The installation complies with the Windows standard including uninstalling the program using the "software" system control. The installation location of the program (target directory) can be freely selected during installation.



Install the software in a directory in which you also have read and write rights.



The start icon  is created automatically on your PC's Desktop.

Uninstalling the software using the system control:

The components are removed from the PC using the Windows "System control".

Under "Software", select "WinPQ mobile" and delete the evaluation software with the "Remove" button.

All parts of the program, including the generated links, are completely removed after a single confirmation. Before uninstalling the program, the components launched must be closed.

Software Update

The evaluation software and all updates are available free of charge on our website under the category "Power Quality":

www.a-eberle.de




Please update both, the software and the firmware of the PQ-Box 50, to avoid problems.

We take care of it


10.2 Software Wizard

If you install the software on a new PC, after the first opening, a setup assistant will start. Customer and country-specific settings are automatically queried and copied into the software. All settings can be changed later in the Software General Settings.


Select language



Select software design (Windows design or Black Magic design)



Setup country specific standard settings



General settings for data export



10.3 WinPQ mobile start screen


Start screen of the evaluation software WinPQ mobile

- Open a measurement on the disk
 - Load the measurement data from the PQ-Box

- Change the PQ-Box setup

- Online measurement with the PQ-Box

Data converter




The screenshot shows the WinPQ mobile software interface. The menu bar at the top includes 'Data', 'View', 'Setup', 'PQ-Box', 'Windows', and 'Help'. The left sidebar contains several tabs: 'Information', 'Details', 'Marker', 'Permanent record', 'Oscilloscope', '10ms RMS', 'PQ-events', 'Ripple control signals', and 'Timing diagram'. The 'Information' tab is active, displaying fields for System, Nominal voltage PE / PP, Frequency, Interval, ripple-control frequency, Start, End, Duration, Number of intervals, PQ-Box Typ, Serial-No., Firmware, and DSP-Version. Below these fields are 'Comments...' and 'More ...' buttons. The 'Permanent record' tab is also visible, showing a 'Selection' list with expandable items: '3 s TRMS values', 'N sec Data' (with sub-items: Frequency, Voltage, Current, Power, Energy), 'N - Min Data', and '2h Data'. The main area on the right is labeled 'Overview data' and contains sections for 'PQ-events:', 'Permanent record:', 'Oscilloscope:', '10ms RMS:', and 'Ripple control signals:'.

10.4 General Software Settings


Changing the language

The evaluation software language can be changed in the "Settings" menu. After changing to a new language, the software must be restarted for the change to take effect.




Changing the colours of lines

Here, each measuring channel can be assigned a specific colour. There are two different settings possible: Windows native and Black magic. For print always the colours Windows native are used.



Export Preferences:

Basic settings for data export



Output Format

Delimiter

☐ Comma (,)

☒ Tabulator (^I)

☐ Space ()

☐ Semicolon (;)

Decimal

☐ Point (.)

☒ Comma (,)

Decimal places: 3

Date / Time

DD:MM:YYYY

hh:mm:ss.###

Options

☐ Suppress Header

☒ Fill gaps

☐ With Linenumbers

☐ With Flagging

☒ Intervall-based

☐ Timestamp-based

OK Cancel

Decimal point separator:
(,) = German Windows
(.) = English Windows


Options:

- Suppress Header – Information like device number, measuring interval and comments will be not in the header of the export file
- Fill gaps – gaps inside the measurement data based on interruption will be filled with 0.
- With flagging: show flagged data according IEC61000-4-30 in export data file
- With exact time stamp: all extreme values are stored with the exact time stamp in milliseconds. For data export format it can be selected to receive the exact time stamp or one time stamp
- Export with exact time stamp: All $\frac{1}{2}$ period extreme values are recorded by the meter with exact time stamps in milliseconds. For the data export it is now possible to choose whether the extreme values should be displayed in milliseconds in the export or whether all min, medium and maximum values should have a common time interval in the export.

We take care of it

General

Change the logo in printouts and headers



The screenshot shows the 'Setup Common' dialog box with several sections and annotations:


- Basics:** Title of IEC report: Auswertung nach EN50160/IEC61000-2-2. Fix Comment 1: Firma. Fix Comment 2: Abteilung. Logo (360x115, 300dpi): Public/Documents/WinPQ mobil/logos/logo32_Eberle.png.
- Statistic Limits:** EN Statistics and Upper Limit table.
- Event Matrix:** Radio buttons for EN50160, Netcode, and NRS 048.
- Header Labels:** Five text boxes for Kunde, Adresse, Kontakt, Telefonnummer, and Grund.
- Co2:** Factor: 550 g/kWh.
- Options:** Checkboxes for Include harmonics in Report, Include tanphi in Report, and Extended Report (checked).

Annotations with arrows point to specific fields:

- Set the header for automatic standard (points to 'Title of IEC report').
- Two predefined comment fields can be set. These will be shown in any printout, as well as in the standard report. (points to 'Fix Comment 1' and 'Fix Comment 2').
- Insert your own logo for printouts and PDF (points to the 'Logo' field).
- 1) Extended standard report: This feature extends the standard report for all PQ event information and the ITIC graphic.
- 2) Standard report including tan phi: The inclusion of the tan phi in the standard report can be switched on or off here (points to the 'Include tanphi in Report' checkbox).
- 5 text boxes for the standard report and all printouts can be specified here (points to the 'Header Labels' section).


These text boxes appear below the "Comment" icon as template text and can be filled here with information about the measurement.

Carbon dioxide calculation



Co2
Factor: 550 g/kWh


The energy supply can be displayed in WinPQ mobil in carbon dioxide. The calculation factor can be set here.



Harmonics settings

Under "Settings / Harmonics Settings", the type of presentation can be set.

- ▶ **Voltage harmonics: Display as "Volt" or "% of the fundamental oscillation"**
- ▶ **Current harmonics / THD, TDD current:**
Display as "Ampere", "% of the fundamental oscillation" or "% of the nominal current"




All diagrams and bar graphs in the software will use the selected units (volts or %; amps or % etc.).

We take care of it

Changing the WinPQ mobile design

WinPQ mobile offers two different designs for screen displays.

- Windows native
- Black magic




Example: "Black magic" design with a black background




With the "Black magic" setting, all print tasks are printed in "Windows native".

10.4.1 TCP-IP Settings in WinPQ mobil



In the analysis software in "Settings / Network Connections", multiple network connections from PQ-Box devices are stored.



- IP address, port number, and a free name of the analyzer can be stored.
- Pick up with "Add" this connection to the software menu.
- "Delete data" deletes the selected IP address from the drop-down menu.
- With "Ping" an IP data connection can be tested.

WinPQ software try to connect always to existing connections. In the software in setup, online data or read out measurement data available devices are selectable.

10.5 Transferring measurement data from the PQ-Box to the PC


Connect the power quality analyzer to the PC with the USB cable or TCP-IP connection.



When the PQ-Box is connected the icon can be used to display all of the available measurement data within the PQ-Box memory.




Press the icon to read the memory of the device.



Loads meas. data from PQ-Box to the PC

Deletes highlighted meas. data from PQ-Box


After reading the data from the device to the PC hard drive, the message "Should the measurement data in the PQ-Box now be deleted?" is displayed.



- Yes – The data will be deleted and the occupied memory in the device is freed.
- No – The measurement data remain stored in the device and can be downloaded from other PCs.



We recommend deleting the measurement data from the device's memory after downloading so that the memory is not filled unnecessarily.




In this view, four comments can be attached to each measurement. If no comment has been entered yet, this field contains "-". Double-click a comment field to edit it.

All four comment fields appear in the printed reports.


10.5.1 Data folder in Windows Explorer

If a text is entered in the first comment field of a measurement file, the folder containing the measurement data will also be called this in Windows Explorer.




10.5.2 Transferring measurement data while a measurement is in progress

To transfer measurement data from the device after a measurement has been started, the measurement is stopped briefly during the data transfer. Confirm the question "Should the recording be stopped?" with "Yes"




Select the measurement data and press the "Transfer data" icon.




The measurement is resumed by pressing the **"Continue"** button.

All of the measurement data are available at the end of the recording in a complete measurement file.





The PQ box appears as data medium via the "Import" card. The "DATA" folder contains all measurement data of the device. Select one or more measurement files and copy them to the PC via the "Import" icon.




10.6 Evaluation of Measurement Data

All measurements available on the PC are listed in the "Hard disk" folder.


The various measurement data can be sorted by "Date" and "Comment" in ascending or descending order. The  button opens the selected measurement for analysis.

The  icon removes the measurement data from the PC's hard disk. More than one measurement can be selected. You will be asked for confirmation before the data is deleted.



With double mouse click on "Comment" you can change the text for the measurement file.

The measurement data can also be opened by double-clicking without the WinPQ mobile start via Windows Explorer. By opening the measurement data folder, you can load "12 Puls-Brückengleichrichter_000" by double-clicking on one of the icons as shown in the example below. The WinPQ mobile starts automatically and opens the selected measurement.



10.6.1 Change the measurement data directory


The button  opens an Explorer window.

Here the folder is assigned in which the measurement data are located.




Do not select the measurement data folder directly but only the parent folder.

Any number of folders with measurement data can be created. These can be located anywhere in the network. Example: A folder for "Measurement data 20kV 2015".



After opening a data file, the information for the whole measuring period is displayed. In the "Evaluation Period" field you can select a specific time period within the measurement and only evaluate this.

Example: A measurement was carried out over 10 days. The standard report is however to be created over a week. By pressing the "1 week" button, the measurement data is limited to one week.



After pressing the "OK" button, the specified period of the selected measurement is opened.

All of the measurements and analyses shown below have been prepared with demo data, which are included in every installation.

We take care of it

Start screen after loading one measurement:

Create a report in accordance with EN50160/IEC61000-2-2 or IEC61000-2-4

Range of the voltage and current harmonics, and the interharmonics. Scaling according to the specified standard

Information about the selected measurement:

- Nominal voltage
- Measurement interval
- Ripple control frequency
- Measurement start
- Measurement end
- Duration of recording
- Number of the measurement interval
- Device number/FW version

EN/IEC report

Here 8 Comment fields can be saved for the measurement All fields appear in the printouts

5 selection tabs:

- Cyclic data
- Oscilloscope images
- 10 ms RMS recorder
- Ripple control signal recorder

Detailed listing of all settings for the measurement (trigger settings, limits, conversion factors ...)

Graphical overview of all measured data and events for the selected measurement

The screenshot displays a software interface for power quality analysis. It features a top menu bar with 'Data', 'View', and 'Setup'. Below this is a toolbar with various icons. The main window is divided into several sections. On the left, there's a sidebar with tabs for 'Marker', 'Information', 'PQ-events', 'Ripple control signals', '10ms RMS', 'Oscilloscope', and 'Print record'. The 'Information' tab is active, showing fields for 'Nominal voltage L-N', 'Interval', 'Ripple-control frequency', 'Start', 'End', 'Duration', 'Number of intervals', 'Serial-No.', 'Firmware', and 'DSP-Version'. To the right of this is a 'Comments...' button. Below the 'Information' tab is a 'Timing data' section with a 'Selection' list containing 'Power', 'Power (15 min)', 'Energy', and 'Energy (15 min)'. The right side of the interface shows a 'Limit' line and a bar chart with three bars labeled 'L1', 'L2', and 'L3'. Below the bar chart is an 'Overview data' section with a table showing 'PQ-events:[19]', 'Permanent record:', 'Oscilloscope:[3]', '10ms RMS:[3]', and 'Ripple control signals:'. A red arrow points from the 'Comments...' button to a text box stating 'Here 8 Comment fields can be saved for the measurement All fields appear in the printouts'. Another red arrow points from the 'Timing data' section to a text box stating 'Detailed listing of all settings for the measurement (trigger settings, limits, conversion factors ...)'. A third red arrow points from the 'Overview data' section to a text box stating 'Graphical overview of all measured data and events for the selected measurement'.

When the mouse pointer is over an icon for the oscilloscope or RMS recorder, information will be displayed for this event.

Overview data

PQ-events:[19]

Permanent record:

Oscilloscope:[3]

10ms RMS:[3]

Ripple control signals:

Display of the daily or weekly changes

Oscilloscope

Time stamp: 13.12.08 / 12:58:25

Trigger: Voltage dip UL1 [ID=1]

The screenshot shows a detailed view of an event. It features a table with three columns: 'Time stamp', 'Trigger', and 'ID'. The first row shows '13.12.08 / 12:58:25', 'Voltage dip UL1', and 'ID=1'. Below the table is a text box stating 'Display of the daily or weekly changes'. A red arrow points from the 'Oscilloscope' icon in the table to a text box stating 'Oscilloscope'.




Clicking on a sign of an oscilloscope recorder, RMS recorder, ripple signal recorder or transient recorder automatically opens the corresponding fault description.

10.6.2 Standard evaluation for EN50160 and IEC61000-2-2



The button gives you a quick overview of all voltage measurement value, with regard to the compatibility levels of the specified standard. In the basic settings, this is the EN50160 and IEC61000-2-2 combined. Depending on the size of the measurement data, the creation of these statistics may take few seconds. In a week of measurements, more than 300,000 measurement values are compared with the corresponding performance level and displayed graphically.

Figure: Example of an EN50160/IEC61000-2-2 evaluation



The bars show in a clear format the 95% reading in red and the highest "100% value" measurement value occurring in blue.

In the example shown, the maximum value of the long term flicker Plt exceeds the standard performance levels in all phases. The 95% value however is far below the permitted limits.

In the basic settings for the standard analysis, it is also possible to set a 100% limit. Should the 100% limit set be exceeded, the blue bar is cross-hatched red.


We take care of it


Harmonic oscillations:


In the bars of the voltage harmonics all the measurements of the 2nd to 50th harmonic are compared with the respective performance level of standards EN50160 and IEC61000-2-2. The harmonic is displayed that is the next to the corresponding limit or exceeds it.


All standard limits can be changed by the user in the software "Configuration / Limits" menu.


List of the standard basic settings for the network analyzer:


PQBox: PQBOX300 Ver:0.000 Sn:1735-201 [COM7] 



Basic settings



Limits


Oscilloscope


10ms RMS recorder


Ripple control


HF Modul


Scheduled Operation

Slow voltage change

Tolerance 99%: positive [%] 110,00 negative [%] 90,00
Tolerance 100%: positive [%] 110,00 negative [%] 85,00

Voltage Changes (Dip/Swell)

Tolerance 100%: positive [%] 110,00 negative [%] 90,00

Network frequency

Tolerance 99.50%: positive [Hz] 50,50 negative [Hz] 49,50
Tolerance 100%: positive [Hz] 52,00 negative [Hz] 47,00

Unbalance

Tolerance 95.00% [%]: 2,00
Tolerance 100% [%]: 3,00


Long term flicker PIt

Tolerance 95.00%: 1,00
Tolerance 100%: 5,00

THD

Tolerance 99% [%]: 8,00
Tolerance 100% [%]: 12,00

Voltage harmonics



THD calculation

☒ H2 - H40
☐ H2 - H50

Grouping of harmonics (U/I)


☒ IEC 61000-4-30 ClassA
☐ Full grouped (EN61000-4-7 Kap.5.5.1)
☐ no grouping

Harmonics: 2
Tolerance 99% [%]: 2,00
Factor 100%: 5,00

Load setup from Box
Send new setup to Box
Load
Store
Basic settings

Close

In the "Details" panel of the standard report, detailed information is given on the respective maximum and minimum value, and the reference to the standard limit.



Information **Plot** Details Harmonics

Info

Nominal voltage: 230V
 Frequency: 50Hz
 Interval: 600s
 Start: 08.04.2007 17:50:00
 End: 15.04.2007 18:20:00
 Duration: 71 0h 29m 59s
 Number of intervals: 1012

Frequency

Maximum value: 50.11 Hz
 95% value: 50.04 Hz
 5% value: 49.97 Hz
 Minimum value: 49.89 Hz
 Limiting value Max: 50.50 Hz
 Limiting value Min: 49.50 Hz
 Number (10sec values): 60717

Voltage changes

	L1	L2	L3
Maximum value:	238.94 V	240.72 V	238.77 V
95% value:	236.52 V	238.13 V	236.27 V
5% value:	227.26 V	227.79 V	227.52 V
Minimum value:	225.64 V	226.10 V	225.84 V
Limiting value Max:	254.03 V	Number (free interval): 1012	
Limiting value Min:	207.85 V		

Voltage unbalance

Maximum value: 0.53
 95% value: 0.32
 Limit value: 2.00
 Number (free interval): 1012

Flicker

	L1	L2	L3
Maximum value:	0.81	1.03	1.06
95% value:	0.48	0.40	0.37
Limiting value Max:	1.00	Number (2h value): 84	

Permanent record **Timing data**


Selection

Example: Standard flicker evaluation

The maximum values for the phases are: L1 = 0.61; L2 = 1.02; L3 = 0.63. As the Plt limit is 1, the bars for the phases L2 exceed the limit line in the overview display. The 95% values (red bars) are all well below the limit.

The "Voltage Harmonics" page shows all the harmonics in a bar chart.

All harmonics are scaled to their limit from the specified standard.





The bars show in a clear format the 95% reading in red and the highest "100% value" measurement value occurring in blue.

In the "Harmonic" page the limits of the selected standard, and the 95% values and maximum values of the individual phases are shown in a table. If a harmonic exceeds the limits, the corresponding row is highlighted in red.

Figure: Detailed listing of the 2nd to 50th harmonics and the respective compatibility levels

EN/IEC report	Details	Harmonics Plot	Harmonics				
	Limiting values	L1 - 95%	L1 - Max	L2 - 95%	L2 - Max	L3 - 95%	L3 - Max
THD	8.0000	3.7028	3.8651	3.7193	3.8347	3.8746	4.0123
2	1.9800	0.0453	0.2403	0.0485	0.1825	0.0476	0.3435
3	5.0000	1.0037	1.1899	1.5526	1.8083	1.2526	1.3641
4	0.9800	0.0341	0.1093	0.0342	0.0620	0.0338	0.1134
5	5.9900	1.7805	1.9978	2.0271	2.2265	2.0183	2.1887
6	0.4900	0.0433	0.0901	0.0435	0.0781	0.0397	0.0860
7	5.0000	1.5627	1.7216	1.3307	1.4671	1.3040	1.4341
8	0.4900	0.0349	0.0643	0.0470	0.0718	0.0317	0.0668
9	1.4800	2.0620	2.2404	1.6792	1.7914	1.6678	1.7670
10	0.4900	0.0465	0.0598	0.0639	0.0711	0.0304	0.0468
11	3.5000	1.2885	1.4374	0.9626	1.1277	0.8011	0.9654
12	0.4900	0.0539	0.0724	0.0654	0.0850	0.0351	0.0562
13	2.9800	1.2765	1.3788	1.1910	1.3007	1.8570	1.9765
14	0.4900	0.0663	0.0849	0.0640	0.0964	0.0472	0.0787
15	0.4900	1.1853	1.4093	1.0159	1.2275	1.1176	1.2282
16	0.4900	0.0497	0.0581	0.0510	0.0756	0.0544	0.0812
17	1.9800	0.9106	1.1839	1.2213	1.4485	0.9030	1.1085
18	0.4900	0.0220	0.0319	0.0308	0.0506	0.0297	0.0547
19	1.4800	0.4927	0.5951	0.7245	0.8352	1.3650	1.5697
20	0.4900	0.0165	0.0226	0.0158	0.0231	0.0202	0.0338
21	0.4900	0.2196	0.2462	0.3041	0.3365	0.5712	0.6424
22	0.4900	0.0150	0.0207	0.0154	0.0185	0.0151	0.0231
23	1.4800	0.2629	0.3045	0.3732	0.4201	0.1470	0.1879
24	0.4900	0.0199	0.0226	0.0237	0.0252	0.0187	0.0271
25	0.4900	0.2350	0.2785	0.3291	0.3818	0.5948	0.6640



Highest value measured in the recording (L1)

95%-value of the measurement (L1)

Limit from the standard

Create EN50160 / IEC61000-2-2 report:

With the Print function, a multi-page standard report opens.

Scroll through the
standard report

Send a report
to the printer

Create PDF
document

Change printer
settings

First

Previous


Next

Last

Print

Export PDF

Printer Setup




a-eberle
GLOBAL NET QUALITY

Standard report EN50160/IEC61000-2-2


20.12.2016
Page 1/5


Company Department	Rundsteuer 250Hz EN50160 - IEC61000-2-2 LV - def	EMPTY EMPTY
Customer:		Phone:
Address:		Reason:
Contact:		SW-Version: 3.1.4 64bit
System:	4-wire System	
Nominal voltage PE / PP	230.00 V / 398.37 V	Interval: 1 s
Frequency:	50 Hz	Ripple-control frequency: 250 Hz
Start:	05.10.2016 08:04:48	End: 05.10.2016 08:11:13
Duration:	6m 25s	Number of intervals: 385
PQ-Box Typ:	PQ-Box 150: ExpertB1 (2-9kHz)	Serial-No.: 9938-004
Firmware:	3.004	DSP-Version: 4.005

Overview




10.6.3 Bar chart of the Harmonics and Interharmonics



Using the two  icons, all voltage and current harmonics, as well as voltage and current interharmonics are displayed graphically or in a table form.

The scaling can be changed in "setup harmonics" from absolute values to relative values.



The example shows the list of all current harmonics of the three phases and neutral. The ordinals 5 and 7, 11 and 13, 17 and 19 stand out. Red bar represents the 95% measured value, the blue bar represents the 100% value.




Table of harmonic values

	L1 - 95%	L1 - Max	L2 - 95%	L2 - Max	L3 - 95%	L3 - Max	
02	2.8521 [A]	3.4658 [A]	2.6505 [A]	3.5537 [A]	2.5926 [A]	3.2562 [A]	
03	1.7764 [A]	2.2264 [A]	1.8707 [A]	2.3933 [A]	1.5029 [A]	1.9265 [A]	
04	1.2930 [A]	1.6541 [A]	1.2510 [A]	1.8606 [A]	1.2403 [A]	1.6760 [A]	
05	88.0763 [A]	106.7447 [A]	88.3021 [A]	107.1785 [A]	87.8084 [A]	106.6618 [A]	
06	1.0791 [A]	1.4184 [A]	1.0394 [A]	1.4161 [A]	1.0252 [A]	1.4987 [A]	
07	25.4768 [A]	32.0951 [A]	26.1785 [A]	33.0616 [A]	25.5559 [A]	32.1389 [A]	
08	0.6486 [A]	0.9401 [A]	0.6441 [A]	0.8871 [A]	0.6309 [A]	0.8007 [A]	
09	0.5818 [A]	0.7895 [A]	0.5549 [A]	0.7112 [A]	0.5185 [A]	0.7063 [A]	
10	0.5378 [A]	0.7709 [A]	0.5205 [A]	0.7113 [A]	0.5028 [A]	0.7268 [A]	
11	24.4563 [A]	30.5683 [A]	24.4522 [A]	30.5124 [A]	24.3625 [A]	30.4375 [A]	
12	0.4965 [A]	0.6506 [A]	0.4973 [A]	0.7355 [A]	0.4640 [A]	0.6367 [A]	
13	11.0046 [A]	14.7722 [A]	11.3741 [A]	15.3005 [A]	11.0889 [A]	14.8478 [A]	
14	0.3423 [A]	0.4776 [A]	0.3570 [A]	0.4720 [A]	0.3331 [A]	0.4413 [A]	
15	0.3337 [A]	0.4499 [A]	0.3349 [A]	0.4376 [A]	0.3039 [A]	0.3993 [A]	
16	0.3181 [A]	0.4593 [A]	0.3323 [A]	0.4456 [A]	0.3126 [A]	0.4064 [A]	
17	12.5913 [A]	15.7555 [A]	12.4908 [A]	15.6298 [A]	12.5218 [A]	15.7005 [A]	
18	0.3317 [A]	0.4455 [A]	0.3349 [A]	0.4393 [A]	0.3082 [A]	0.4272 [A]	
19	7.0123 [A]	9.5618 [A]	7.3320 [A]	10.0010 [A]	7.0974 [A]	9.5995 [A]	
20	0.2396 [A]	0.3149 [A]	0.2420 [A]	0.3224 [A]	0.2352 [A]	0.3055 [A]	
21	0.2378 [A]	0.3196 [A]	0.2341 [A]	0.3165 [A]	0.2211 [A]	0.2829 [A]	
22	0.2334 [A]	0.3069 [A]	0.2334 [A]	0.3146 [A]	0.2301 [A]	0.2942 [A]	
23	7.6396 [A]	9.3913 [A]	7.5836 [A]	9.2955 [A]	7.6189 [A]	9.3453 [A]	
24	0.2514 [A]	0.3249 [A]	0.2534 [A]	0.3468 [A]	0.2290 [A]	0.3186 [A]	
25	4.8823 [A]	6.5485 [A]	5.1987 [A]	6.9194 [A]	4.9771 [A]	6.5909 [A]	
26	0.1847 [A]	0.2600 [A]	0.1909 [A]	0.2500 [A]	0.1801 [A]	0.2174 [A]	

10.6.4 D-A-CH-CZ report

The software produces an automatic report according the D-A-CH-CZ standard.

All current harmonics will be compared to the maximum allowed limit of this standard. You have to fill the “short circuit power” of the network, the connected load and the nominal voltage.

Harmonics Plot
Interharmonics Plot
Harmonics Details
Interharmonics Details
D-A-C-H - CZ

Short circuit power [kVA]:

Connection Load [kVA]:

Nominal voltage L-L [V]:

valid THDi [%]:

voltage h...	Standard factor value		max. emission limit [A]		meas. harm. values [A]	
	L1 - L3	N	L1 - L3	N	L1 - L3	N
H 3	6.0	18.0	21.7	65.2	2.4	1.2
H 5	15.0		54.3		107.2	
H 7	10.0		36.2		33.1	
H 11	5.0		18.1		30.6	
H 13	4.0		14.5		15.3	
H 17	2.0		7.2		15.8	
H 19	1.5		5.4		10.0	
H 21	1.0		3.6		0.3	

DACH-CZ report compare all current harmonics to the limits. Red values are above the thresholds.

Details						
DACH-CZ: NOT COMPLIED						
voltage harmonics	Standard factor value		max. emission limit [A]		meas. harm. values [A]	
	L1 - L3	N	L1 - L3	N	L1 - L3	N
H 3	6.0	18.0	21.7	65.2	2.4	1.2
H 5	15.0		54.3		107.2	
H 7	10.0		36.2		33.1	
H 11	5.0		18.1		30.6	
H 13	4.0		14.5		15.3	
H 17	2.0		7.2		15.8	
H 19	1.5		5.4		10.0	
H 21	1.0		3.6		0.3	
H 23	1.0		3.6		9.4	
H 25	1.0		3.6		6.9	

10.6.5 Level-time diagrams of the long-term data

In the "Cyclic data" menu item all permanent recorded measurement data are listed. In each measurement more than 3800 different measurement values (voltage, harmonics, interharmonics, current, power and energy) are saved. Any measurement values can be displayed together in a level-time diagram. Thus, for example, a relationship between the voltage fluctuations, the resulting flicker level and the cause in the network can be shown by means of the associated current changes.


Selecting the required parameter (or multiple parameters)  and pressing the **Timing diagram** button displays the level-time diagram of the required measurement value.

Figure: Level-time diagram of the 10 ms minimum value of the voltages L1, L2, L3




We take care of it

Zoom function in the graphic:



To magnify an area, activate the zoom function. Then pull with the left mouse button pressed, a window from the top left to bottom right. If the window is drawn in the opposite direction, the magnification is reset.



Bars represent the zoomed area.

The moving the bar you can scroll through the measurement

Move graphic:



When the "Move" button is pressed, the graphic can be moved freely in the time axis and value axis.

Place a marker:



Using the "Marker" button, two markers can be positioned in the graphic.



Two markers can be set in the plot using the left mouse button. This selects the closest curve and the marker acquires its colour.

- **Marker No. 1** with the left mouse button and Shift
- **Marker No. 2** with the left mouse button and Control key


The distance between the two markers is determined as an absolute value. The time interval is always calculated; the difference value is calculated only with identical units.



With long measurement intervals set (e.g. 10 min) for the extreme values (10 ms), the exact times is shown in milliseconds in the marker.


We take care of it

Representation of line styles



Four types of representation are offered for lines.


- 1st. Connects every measured point together (default for all graphs)
- 2nd. Represents only the measurement points, the points are not connected by lines
- 3rd. This level representation is particularly suitable for medium values, such as 15 minutes performance data. Here, the mean value over the measuring period is represented as a straight line.



- 4th. The "inverted level representation" enables network interruptions to be clearly shown in the level-time diagram.

Other functions in the right mouse menu:

- **Delete marker** – If one marker is set, it is possible to delete the marker
- **Flagging representation** = measurement data that were obtained during a network failure or interruption are marked (flagged). Here the marking can be toggled on and off.
- **Left axis scaling** = the left measurement axis can be scaled manually
- **Right axis scaling** = the right measurement axis can be scaled manually
- **Logarithmic axis scaling**
- **Share axes automatically** = SW automatically separates meaningful readings with their own scale so that no measurement values overlap .
- **Scale axes automatically** = SW automatically scales to the maximum and minimum values over the entire screen
- **Limit line setting** = the value and colour of a limit line can be set
- **Complete data** = the whole measurement period is shown
- **Data 1 day** = the time scale is set to one day
- **Data 7 days** = the time scale is set to exactly one week
- **Data 2 weeks** = the time scale is set to 14 days
- **Data 4 weeks** = the time scale is set to 1 month
- **Insert Comment** = This function enables a comment to be inserted into the graph. This will also appear in the printout.
- **Print** = the current graphic will be sent to the selected printer or saved as a PDF document
- **Clipboard** = The graphical display is copied to the clipboard. Then, for example, the graphic can be pasted into an **MS-WORD™** document




Limit Line Setting

In the "Limit line setting" menu option it is possible to define multiple limit lines.


The colour, value, and the corresponding y-axis of the limit line can be set.

Example: Limit line for the voltage; 207 V (-10% Unenn)



Show limit marker harmonics

The software automatically suggests the thresholds for harmonics, voltage, unbalance or flicker. The threshold can be a %-value or an absolute value, depending on the settings of the harmonics.




Insert and edit comment

With the "Insert comment" function, any number of texts can be placed in the graphic.

To delete or move this term in the graph, click it with the mouse so that it turns red.

Now, using the Windows "remove" function the text can be deleted or moved using the mouse.

With double mouse click it is possible to edit the comment.




We take care of it


10.6.6 Oscilloscope recordings

With the "Oscilloscope" tab, all manually recorded and using oscilloscope trigger settings images are listed. These can be sorted by time, or trigger condition.


By double-clicking on the line, or by pressing the  button, you will get the relevant oscilloscope image.

For each fault record, all voltages "Conductor to Conductor" and "Conductors to ground" are recorded.





You can scroll through the triggered images using the two  keys. The software remembers the settings for the previous image and shows all other images with the same representation (e.g. in the example, only the voltage channels without the current)

"Right mouse" menu:




Calculation of the FFT spectrum is possible by activating the "FFT" field of each triggered oscilloscope image.

- PQ-Box 50 = DC to 10.000Hz




The markers fields in the FFT analysis show the selected frequency and amplitude in the spectrum.




We take care of it


10.6.7 ½ periode rms RMS Recorder

With the "10ms RMS" tab, all RMS recordings manually recorded and using trigger settings are listed.

These can be sorted by time, or trigger condition. Double-clicking the line or pressing the  button retrieves the corresponding 10 ms RMS recorder value.




Listing all 10 msec. RMS recorder recordings

You can scroll through the triggered images using the two  keys. The software remembers the settings for the previous image and shows all other images with the same representation (e.g. in the example, only the voltage channels without the current)



10.6.8 Ripple Control Signal Recorder

With the option “**R1-Ripple signal recorder**” it is possible to trigger to the signal voltage and start a record especially for this frequency. The maximum length of the recorder is 210 seconds. There are recorded the voltages and currents

In this example the frequency of 180 Hz was recorded over 1 minute and 40 seconds.




All ripple control records are shown in the recorder list and in the overview picture


With these two icons   it is possible to scroll through the different recorders

With the "PQ Events" tab, all violations of the specified limits are displayed.



List table



ITIC




Using WinPQ mobile / Settings / General, these statistics from Evaluation to NRS 048 (South Africa PQ standard).




10.6.10 Data export – Interval data

Using "Settings / Export", it is possible to set basic parameters for the measurement data export.

The decimal point separator in a German Windows is a comma; in the English-language Windows it is a full stop.




Using "Data / CSV Export", all measurement interval data can now be exported for open, for example, in MS Excel.




In the following menu, all measurement values can be selected and exported with the "Export" button to a file.

Using "Save", various selection for data export can be saved (e.g. file export of all harmonics). With load already stored files can be opened.



Any name can be specified for the export file. The file is saved in the PQ-Box / Export directory.



We take care of it

Example of an export file in MS Excel:

	A	B	C	D	E	F	G	H	I	J	K
1	PQ Box 100		Serial-No.: 0804-004								
2											
3	Measurement: Solar plant, Hofweg 28,										
4											
5	Interval: 600 sec										
6	Voltage: 230 V										
7											
8											
9	Date/Time: 18.11.2008 12:40:00 - 26.11.2008 09:50:00										
10											
11	Date	Time	P L1	P L2	P L3	P total	S L1	S L2	S L3	S total	Q L1
12	18.11.2008	12:40:00	28970.9	29141.8	28623.1	86735.7	33268.4	32337.8	32861.8	98529.4	16354.6
13	18.11.2008	12:50:00	35467.8	35369.3	35821.7	106659	38617.5	36427.2	38791.4	113940	15275.8
14	18.11.2008	13:00:00	37027.4	36698.5	37197.9	110924	39811.1	37975.3	39840.5	117718	14625.3
15	18.11.2008	13:10:00	30077.2	30896.3	30015.8	90989.1	33151.5	32195	32980.1	98415	13942.7
16	18.11.2008	13:20:00	28710.2	29336.5	29443.2	87489.9	30632.4	30212.2	31295.6	92214.9	10680.1
17	18.11.2008	13:30:00	36482.6	37915.5	36829	111227	39502.6	39227.4	39710.5	118495	15148.7
18	18.11.2008	13:40:00	29710.6	30129.8	29647	89487.3	33692.9	31855.7	33216.9	98892.1	15890.1
19	18.11.2008	13:50:00	39636.2	40203.4	39142	118982	42011.7	41812.8	41045.9	124953	13926.7
20	18.11.2008	14:00:00	32961.5	32672.7	31729.8	97364	35817.4	34063.2	34084.7	104121	14015.2
21	18.11.2008	14:10:00	24075.5	24809.9	23199.5	72085	26868	25623.7	25789.5	78576.4	11927.1
22	18.11.2008	14:20:00	30752.7	31526.1	30099.9	92378.7	33938.8	32864.1	32846.5	99826	14356.6



The order of the selected data in data export is automatically the order of columns in the export file.

In CSV export you will have the minimum - and maximum - RMS output with the exact time stamps.

Options

☐ Suppress Header
 ☐ Fill gaps

☐ With Linenumbers
 ☐ With Flagging


☒ Intervall-based
 ☐ Timestamp-based

The time format for CSV Export can be changed in general settings for export data

Also, the Short Time Flicker (PST) and the Long time Flicker (PLT) have it's own time stamps regardless of the programmed measurement interval as 10 min interval is issued.

Datum/Zeit: 17.10.2013 09:30		06:50:00								
Datum	Zeit	UL1	UL2	UL3	UL1 max	UL2 max	UL3 max	UL1 min	UL2 min	UL3 min
07.10.2013	09:30:00	232,56	232,539	233,323						
07.10.2013	09:35:39					233,004				
07.10.2013	09:35:44						233,999			
07.10.2013	09:38:16				233,124					
07.10.2013	09:39:01							230,728		
07.10.2013	09:39:01								230,506	231,44
07.10.2013	09:40:00	232,572	232,487	233,394						
07.10.2013	09:40:27						233,874			
07.10.2013	09:43:50								231,299	232,322
07.10.2013	09:49:00				233,116					
07.10.2013	09:49:00					233,107				
07.10.2013	09:49:30							231,209		
07.10.2013	09:50:00	232,51	232,412	233,318						


With the feature "Fill gaps" measurement interruptions will be filled with zero values.



Datum	Zeit	'UL1 [V]'	'UL2 [V]'	'UL3 [V]'	'UL1 max [V]'	'UL2 max [V]'	'UL3 max [V]'	'UL1 min [V]'	'UL2 min [V]'	'UL3 min [V]'	'IL1 [A]'	'IL2 [A]'	'IL3 [A]'	'I Neutral [A]'	'IL1 Max [A]'	'IL2 Max [A]'	'IL3 M
01.04.2016	05:10:00.000	271.283	275.863	270.185	271.919	276.491	270.827	269.174	274.863	268.923	483.327	511.903	475.153	2.532	489.030	520.794	4
01.04.2016	05:20:00.000	271.176	275.864	270.134	272.041	276.776	270.911	266.244	271.936	264.533	483.976	512.775	476.001	2.584	507.876	540.824	4
01.04.2016	05:30:00.000	272.163	276.583	270.990	272.676	277.101	271.544	269.445	275.224	269.690	483.283	510.335	473.954	2.574	489.797	525.497	4
01.04.2016	05:40:00.000	272.324	276.556	271.203	272.900	287.965	276.910	175.906	262.996	258.264	483.457	509.221	474.873	2.559	701.583	895.008	6
01.04.2016	05:50:00.000	272.216	276.055	270.999	276.221	279.873	274.843	257.461	260.527	256.539	478.912	504.267	472.828	2.590	810.285	849.971	8
01.04.2016	06:00:00.000	274.798	279.002	273.612	275.324	279.678	274.152	273.097	277.789	272.422	367.563	385.975	359.205	2.002	382.301	402.349	3
01.04.2016	06:10:00.000	274.875	278.879	273.465	275.364	279.403	274.052	273.792	277.889	272.460	367.464	384.099	357.608	2.001	371.021	387.841	3
01.04.2016	06:20:00.000	273.572	277.434	271.984	274.937	278.942	273.517	258.707	262.495	256.860	454.392	474.790	443.088	2.428	971.944	1.011.982	9
01.04.2016	06:30:00.000	273.935	277.786	272.189	274.357	278.254	272.611	273.290	277.178	271.608	484.630	506.019	471.180	2.578	488.557	509.808	4
01.04.2016	06:40:00.000	273.603	277.804	271.985	274.187	278.434	272.504	273.104	277.079	270.531	483.665	506.959	469.497	2.573	492.795	510.591	4
01.04.2016	06:50:00.000	273.318	277.704	271.783	274.863	279.241	273.274	273.648	276.464	269.376	483.641	508.505	469.488	2.583	495.022	519.829	4
01.04.2016	07:00:00.000	272.719	277.356	271.312	274.428	279.222	273.166	267.584	274.644	265.968	483.577	510.151	470.616	2.568	509.003	532.637	4
01.04.2016	07:10:00.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
01.04.2016	07:20:00.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
01.04.2016	07:30:00.000	271.370	276.053	270.290	272.101	276.797	271.214	268.478	274.057	266.689	485.299	511.619	472.537	2.576	499.676	529.348	4
01.04.2016	07:40:00.000	271.203	275.780	269.894	271.855	276.430	270.460	269.144	274.073	268.600	486.857	511.288	472.643	2.573	492.777	524.878	4
01.04.2016	07:50:00.000	271.833	276.470	270.451	273.298	277.945	271.870	268.370	273.023	268.168	485.391	510.938	471.766	2.552	496.792	523.589	4
01.04.2016	08:00:00.000	272.188	276.863	270.839	272.829	277.586	271.501	269.882	275.163	268.022	483.957	509.124	470.683	2.516	494.502	520.687	4
01.04.2016	08:10:00.000	272.631	277.394	271.318	274.412	279.321	273.401	262.514	267.480	261.272	455.861	479.871	443.723	2.339	802.930	841.529	8
01.04.2016	08:20:00.000	273.252	278.387	272.129	274.491	279.595	273.301	270.917	276.895	269.314	365.707	386.118	354.603	1.907	373.335	390.746	3
01.04.2016	08:30:00.000	272.364	277.592	271.256	273.230	279.464	272.320	215.401	267.423	266.888	370.111	391.976	359.718	1.945	452.832	552.734	4
01.04.2016	08:40:00.000	271.453	276.559	270.260	272.904	277.958	271.591	270.356	275.560	269.245	371.568	393.983	361.710	1.974	386.928	408.464	3
01.04.2016	08:50:00.000	272.355	277.624	271.147	272.829	278.079	271.616	269.892	276.400	269.976	370.809	391.864	359.285	1.961	375.008	402.604	3
01.04.2016	09:00:00.000	272.348	277.488	271.108	272.814	277.939	271.609	271.506	274.913	270.548	371.115	391.664	359.167	1.939	373.925	394.946	3
01.04.2016	09:10:00.000	271.936	276.954	270.820	272.751	277.968	271.806	268.822	275.860	269.619	371.944	391.588	360.324	1.947	375.136	406.871	3
01.04.2016	09:20:00.000	271.860	276.784	270.721	272.351	277.231	271.250	269.976	275.709	268.667	370.965	390.672	359.837	1.939	378.106	396.025	3
01.04.2016	09:30:00.000	271.655	276.642	270.668	272.369	277.249	271.430	268.689	274.576	267.302	371.617	391.268	360.750	1.945	383.970	403.924	3
01.04.2016	09:40:00.000	271.898	276.897	270.987	276.420	281.923	275.758	264.022	269.337	263.041	353.857	372.914	343.972	1.902	605.231	636.503	6


10.6.11 Additional functions

Using the "Window / Split" menu item it is possible to display all previously selected evaluations together in an overview.



We take care of it

The "information" and "Measurement data overview" fields can be closed to give more space for the evaluation graphics. These can be re-displayed with the "View" field.




"Measurement data overview" close field


Comparing two separate measurement files.


During an evaluation, it is possible to open another measurement, start level-time charts and standard evaluations, display them next to one another in an image and compare them.

Figure: Two separate measurements displayed next to one another
(2 x EN50160 report; 2 x level-time diagrams)



11. PQ-Box Limits and Settings

With the Setup“ icon  you can change the device parameters, trigger conditions and limits.



The screenshot shows the PQ-Box software interface. On the left is a sidebar with icons for Basic settings, Limits, Oscilloscope, 10ms RMS recorder, Ripple control, Scheduled Operation, and Update device. The main area is divided into several sections: Configuration (Identification, Network), Measuring parameter (Nominal voltage, Measuring interval), Device connection (4 Leiter-Netz), Transducer factor (Voltage, Current, Phase), Data recording (Only voltage, Only Basicdata, Full 3 sec recording, Full 200 msec recording, Power interval), AUX input, Flicker curve (230 V curve, 120 V curve), and Power measurement (Unbalance: on/off, Modulation: on/off). On the right side, there is a yellow-bordered box containing four buttons: Load setup from Box, Send new setup to Box, Load, and Store. Below this box is a Basic settings button. At the bottom right is a Close button.

Load setup from Box

Loads the current settings from the network analyser to PC screen

Send new setup to Box

Sends currently displayed settings to the PQ-Box

Load

Opens a template file of settings, which has previously been stored on the PC

Store

Saves a setup file to the PC

Basic settings

Resets displayed settings to default values. (Please note these still need to be “sent” to the PQ-Box to take effect). The Basic settings button loads all settings from the stored file “PQBox_Param_default.ini” This file can be overwritten if you desire to create your own default settings. Note that each setting file contains all the “Basic Settings”, “Limits”, “Oscilloscope” & “10ms RMS recorder” setting values. These are not stored individually.



This function can start and stop a measurement on the meter from the software.

11.1 Setup - Basic Settings



Basic settings


In the Basic Settings menu, settings such as the network configuration, nominal voltage and transmission ratio of current and voltage transformers are set.

Voltage configuration:

- 1 wire system (single phase L1)
- 3 wire system (insolated network)
- 4 wire system (L1, L2, L3, N, earth)
- V-circuit (This function is activated if the secondary voltage transformer in the medium or high-voltage network is connected in a V-connection. The power connection U2 is at ground.)
- Delta high leg network
- Split phase network

With the 3-wire or 4-wire the device distinguishes the configuration of the network to be measured. In an isolated 3-wire network, all ratings from the EN50160 standard are calculated from the wire voltages. In a 4-wire network (grounded network) all Power-Quality parameters are derived from the phase voltages. For single phase measurement only phase L1, N and PE will be recorded.


8 configurations are available for PQ-Box connection.



This function is activated if the secondary current transformer in the medium or high-voltage network is connected in an Aron-connection. The current L2 is not connected and calculated by the PQ-Box.

We take care of it

It is possible to describe the measurement/setup with user defined text (up to 32 characters). After the measurement is done, this text can be found in “Comment 2”.



Nominal voltage PE / PP [V]:	230,00	398,37
------------------------------	--------	--------

The PQ-Box bases all trigger thresholds and PQ events on the set “Nominal voltage”.

The contractually agreed voltage should be specified as the nominal voltage in all network configurations, e.g. 230 V or 20500 V

Measuring interval [sec]:	600
---------------------------	-----

The measuring interval of the PQ-Box can be set to any value within the range of one second to 1800 seconds. The default setting is 10 minutes as this is the interval specified in the EN50160 and IEC61000-2-2 standards.

Data recording of PQ-Box

The resulting data size can be strongly influenced at this point.

Data recording

☐ Only voltage
 ☐ Only Basicdata
 ☐ Full 3 sec recording
 ☐ Full 200 msec recording

Power interval: 15 min ▼

● Only voltage

In this setting, no currents and power values are recorded. The amount of data reduced to about 40%.

Only Basic data

In “Basic data” no harmonics, interharmonics or phase angle of harmonics will be recorded. All recorders are still active.

● Measuring interval 200ms / 3 sec

Parallel to the free data class (1sec to 30min), the two data classes can be activated for 3 seconds and / or 200ms



Note - data quantity

These two data classes are only suitable for short measuring periods and produce a very large amount of data. The same applies to the setting of the free measuring interval less than 60 seconds. The fault records additional increase the memory.

Examples of the data size:

- The free measurement interval of **10 minutes (600 seconds)** produces a data size of about **15 MB in a week**
- The free measurement interval of **1 second** produces a data size of about **15 MB in 30 minutes**
- The 200 ms interval produce a data size of about **80MB per one hour**
- The 3 sec interval produce a data size of about **5MB per one hour**

● Power interval

All power values are also recorded at the freely adjustable interval of 10, 15 or 30 minute intervals.

These intervals always start in sync with the full hour.

Example: If recording is started at 14:37, and 15 minute interval has been selected, the first valid power date interval will be 14:45 to 15:00.

Measurement values in basic data:

☐ Only Basicdata

Status, Events, Flagging
Frequency values (mean, extreme)
Voltage values (mean, extreme)
Flicker
Current values (mean, extreme)
Power values (mean, extreme)
Ripple signal voltage
THC, K-Factor, Phaseangle, symmetrical components
Distortion power, Power factor
Spannungsabweichung, Symmetrie, PWHD
PWHD, PHC current
cosPhi, sinPhi, tanPhi, power values fundamental
Reactive power fundamental
10/15/30-minutes interval
Power values (mean, extreme)
Distortion power, Power factor
cosPhi, sinPhi, tanPhi, power values fundamental
Reactive power fundamental

Example for basic data:

- One measurement file with 1 sec interval produces about 6,6 MB data per hour.
- 1 GB memory will be filled in 6,6 days.

Transducer factor voltage and current

Transducer factor

Voltage		Current		<input type="checkbox"/> Phase
UL1:	1,000	I1:	1,000	
UL2:	1,000	I2:	1,000	
UL3:	1,000	I3:	1,000	
UNE:	1,000	IN:	1,000	

In the converter settings the transmission ratio of current and voltage transformers to which the network analyzer is connected is entered.

Example: Voltage: primary = 20,000 V; secondary = 100 V; Conversion factor UL1 = 200
 Current: 100 A / 5 A = Conversion factor 20

Note the CT ratios also need to be adjusted for certain CT clamps.

Phase angle correction

Transducer factor

Voltage		Current		<input checked="" type="checkbox"/> Phase	
UL1:	1,000	I1:	1,000	phi L1:	1,000
UL2:	1,000	I2:	1,000	phi L2:	1,000
UL3:	1,000	I3:	1,000	phi L3:	1,000
UNE:	1,000	IN:	1,000	phi N:	1,000

With the function "Phase correction current clamps" it is possible to correct the phase angle error of a current clamp or an external current transformer. This function is only available for current clamps with magnetic core. Rogowski coils typically have no phase error and therefore do not need to be corrected.

For correction, the phase error of the associated current clamp at the nominal frequency of the mains (50/60 Hz) is entered into the field of the respective phase. The following figure shows the typical course of the phase error over the frequency of the measured signal. The phase error of these current transformers is always positive (capacitive). It can therefore be corrected in the WinPQ mobil software in a range between 0 and +5°. Example: 1,000 means a phase angle correction of an error of +1°.

Attention: A DC current measurement is only possible with deactivated function "Phase correction".





Figure: Phase and amplitude response of a current clamp with magnetic core

Setting of Power measurement

The calculation of the power values can be changed in different settings:



Power measurement

<input type="radio"/> Unbalance: on Modulation: off	<input checked="" type="radio"/> Unbalance: on Modulation: on	← Basic setting
<input type="radio"/> Unbalance: off Modulation: off	<input type="radio"/> Unbalance: off Modulation: on	

This setting on power calculation has also an effect on the power values in the display of the PQ-Box and the online values.

- Power measurement with calculation of the unbalance reactive power and modulation reactive power is the basic setting of the PQ-Box.

11.2 Setup – EN50160 / IEC61000-2-2 / IEC61000-2-4 Limits



Limits

In this menu item, all the limits from the EN50160 and IEC61000-2-2 standard are present. The compatibility levels can be changed by the user.

Using the **Basic settings** button, all the limits are reset to the standard values.

Slow voltage change

Tolerance 95%: positive [%] 110,00 negative [%] 90,00

Tolerance 100%: positive [%] 110,00 negative [%] 85,00

Voltage Changes (Dip/Swell)

Tolerance 100%: positive [%] 110,00 negative [%] 90,00

Rapid voltage change

Tolerance band [%] 1,00 Detection limit for RVC [%] 5,00

Network frequency

Tolerance 99.50%: positive [Hz] 50,50 negative [Hz] 49,50

Tolerance 100%: positive [Hz] 52,00 negative [Hz] 47,00

Unbalance

Tolerance 95% [%]: 2,00

Tolerance 100% [%]: 3,00

Long term flicker PIt

Tolerance 95%: 1,00

Tolerance 100%: 5,00

THD

Tolerance 95% [%]: 8,00

Tolerance 100% [%]: 12,00

Voltage harmonics

THD calculation

☒ H2 - H40

☐ H2 - H50

Grouping of harmonics (U/I)


☒ IEC 61000-4-30 ClassA

☐ Full grouped (EN61000-4-7 Kap.5.5.1)


Harmonics: 2


Tolerance 95% [%]: 2,00

Factor 100%: 1,50




As the EN50160 only specifies limits for harmonics up to the 25th ordinal, in the PQ-Box 200 basic settings the compatibility level from IEC61000-2-2 for the 26th to 50th harmonics are stored.

The  button enables different configurations stored on the PC to be opened. The IEC61000-2-4 limit files for industrial networks are also stored in the templates.

With the  icon any number of settings templates can be stored for the PQ-Box 200.


THD calculation



The THD calculation of voltage and current can be changed in the settings:

- 2 – 40th
- 2 – 50th

Calculation of harmonics



The calculation method for the harmonic groupings can be adjusted depending on the application (PowerQuality measurement or equipment testing).

- IEC61000-4-30 class A calculation
- Full grouping according IEC61000-4-7 section 5.5.1 (IEC 61000-3-X)
Harmonic calculation (f. e. 2. Harm. = 75Hz bis 125Hz).
Interharmonics. (f. e. IH1 55Hz bis 95Hz)
- No grouping – single frequency

11.3 Oscilloscope trigger settings



Oscilloscope

In the "Oscilloscope" menu item, trigger criteria can be set for the oscilloscope. In the default setting an RMS value threshold of +10% and -10% of the nominal voltage is set.

If a field is greyed out ☐ and not checked, this trigger criterion is not active.

All trigger conditions can be operated in parallel and work in "or operation".

	Untere Triggerschwelle [%]	Obere Triggerschwelle [%]	Effektivwertsprung [%]	Phasensprung [°]	Hüllkurventrigger [%]
UL1:	<input checked="" type="checkbox"/> 90	<input checked="" type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input checked="" type="checkbox"/> 20
UL2:	<input checked="" type="checkbox"/> 90	<input checked="" type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input checked="" type="checkbox"/> 20
UL3:	<input checked="" type="checkbox"/> 90	<input checked="" type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input checked="" type="checkbox"/> 20
UNE:	<input type="checkbox"/>	<input type="checkbox"/> 30	<input type="checkbox"/> 10	<input type="checkbox"/>	<input type="checkbox"/> 20
U12:	<input type="checkbox"/> 90	<input type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input type="checkbox"/> 20
U23:	<input type="checkbox"/> 90	<input type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input type="checkbox"/> 20
U31:	<input type="checkbox"/> 90	<input type="checkbox"/> 110	<input type="checkbox"/> 10	<input type="checkbox"/> 6	<input type="checkbox"/> 20
IL1:	<input type="checkbox"/> 10	<input type="checkbox"/> 3000	<input type="checkbox"/> 300	<input checked="" type="checkbox"/> Automatik Trigger	
IL2:	<input type="checkbox"/> 10	<input type="checkbox"/> 3000	<input type="checkbox"/> 300		
IL3:	<input type="checkbox"/> 10	<input type="checkbox"/> 3000	<input type="checkbox"/> 300		
IN:	<input type="checkbox"/>	<input type="checkbox"/> 3000	<input type="checkbox"/> 300		

☐ Externer Trigger (Binäreingang PQ-Box200)

☒ fallende Flanke ☐ steigende Flanke

☐ Intervalltrigger

[min]

Hüllkurventrigger

Totzeit Hüllkurventrigger [s]:

Hysteresis

Hysteresis 10ms RMS Spannung [%]: Hysteresis 10ms RMS Strom [A]:

Aufzeichnungslänge / Vorgeschichte

Vorgeschichte: [msec] Aufzeichnungsdauer: [msec]

The "Recording Time" is the total recording time for the oscilloscope in milliseconds.

As "History", the time is defined that was recorded before the occurrence of the event.

The length of the oscilloscope image, and the history can be set to any value between 20 ms and 4,000 ms.

Automatic trigger for oscilloscope recorder: If enabled, then the PQ-Box changes all activated trigger thresholds on this page automatically in a limit setting is too sensitive. This prevents unnecessarily large amounts of data being recorded. The "Automatic Trigger" acts selectively on each threshold and increases it. If the network is without any problems, the limits automatically go back to the threshold in the setup.

If enabled, an oscilloscope recorder is recorded according to the interval of time. With WinPQ mobil it is possible to calculate the spectrum of the recorder with the integrated FFT functionality.

Explanation of the trigger conditions:

If the trigger thresholds are indicated in "%", this value refers to the nominal voltage set in the setup, e.g. 20,300 V or 400 V.

lower threshold

[%]

Starts a trigger recording on exceeding the set trigger threshold.
Trigger bases are the 10 ms RMS value.

upper threshold

[%]

Starts a trigger recording on exceeding the set trigger threshold.
Trigger bases are the 10 ms RMS value.

step

[%]

Starts a trigger recording on an RMS value jump of the specified amount.
Trigger bases are the 10 ms RMS value.

phase step

[°]


Starts a trigger recording on a phase jump.
The trigger base is a displacement of the sine wave zero crossings in "°".

envelope

[%]

Starts a trigger recording on a sine wave violation. The measurement device identifies a violation of the sine curve on scanning. (e.g. commutation notch)
A reasonable setting of the threshold value is between 10% and 25% of the nominal voltage.

Example of a commutation notch:



Break time envelope trigger:

The break time envelope trigger can very quickly produce a very large number of oscilloscope images. To reduce the amount of data you can set a fixed time interval between the individual recordings.

Example: break time = 5 seconds

At the end of an oscilloscope recording the trigger condition "envelope trigger" is deactivated for 5 seconds. All other trigger settings continue to work without a deadtime.

Hysteresis: In the IEC61000-4-30 standard a hysteresis is provided for events.

Example: Limit for a voltage dip = 90% - Hysteresis = 2%

A network breakdown begins with the 90% limit line being exceeded and is ended when the network voltage reaches 92% (+2%) again.

11.4 ½ period rms Recorder



10ms RMS recorder

In the "rms (1/2 period)" menu item, trigger criteria can be set for the rms recorder. In the default setting an rms value threshold of +10% and -10% of the nominal voltage is set.

Only the threshold values with a tick are active, trigger conditions without ticks are not switched on.

- Basic settings
- Limits
- Oscilloscope
- 10ms RMS recorder
- Ripple control
- HF Modul
- Scheduled Operation

voltage- / current trigger

	lower threshold [%]	upper threshold [%]	step [%]	phase step [°]
UL1:	<input checked="" type="checkbox"/> 90,00	<input checked="" type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
UL2:	<input checked="" type="checkbox"/> 90,00	<input checked="" type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
UL3:	<input checked="" type="checkbox"/> 90,00	<input checked="" type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
UNE:	<input type="checkbox"/> 0,00	<input type="checkbox"/> 30,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 0,00
U12:	<input type="checkbox"/> 90,00	<input type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
U23:	<input type="checkbox"/> 90,00	<input type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
U31:	<input type="checkbox"/> 90,00	<input type="checkbox"/> 110,00	<input type="checkbox"/> 10,00	<input type="checkbox"/> 6,00
	[A]	[A]	[A]	
IL1:	<input type="checkbox"/> 10,00	<input type="checkbox"/> 3000,00	<input type="checkbox"/> 300,00	<input checked="" type="checkbox"/> Auto-Trigger
IL2:	<input type="checkbox"/> 10,00	<input type="checkbox"/> 3000,00	<input type="checkbox"/> 300,00	
IL3:	<input type="checkbox"/> 10,00	<input type="checkbox"/> 3000,00	<input type="checkbox"/> 300,00	
IN:	<input type="checkbox"/> 0,00	<input type="checkbox"/> 3000,00	<input type="checkbox"/> 300,00	

frequency trigger

	lower threshold [Hz]	upper threshold [Hz]	frequency change [df/ 1s]
F:	<input type="checkbox"/> 49,50	<input type="checkbox"/> 50,50	<input type="checkbox"/> 0,50

☐ External Trigger

☒ falling Edge ☐ rising Edge

Hysteresis

Hysteresis 10ms RMS voltage [%]:

Hysteresis 10ms RMS current [A]:

Parameter

pre-event time: [sec] Recorder time: [sec]

Explanation of the trigger conditions additional to oscilloscope trigger 12.3:

frequency trigger

	lower threshold [Hz]	upper threshold [Hz]	frequency change [df/ 1s]
F:	<input type="checkbox"/> 49,50	<input type="checkbox"/> 50,50	<input type="checkbox"/> 0,50

The ½ period rms recorder can be triggered on lower or upper threshold of the frequency or a frequency change within one second.

The "Recorder Time" is the total recording time for the oscilloscope in seconds.

As "pre event time", the time is defined that was recorded before the occurrence of the event.

The length of the recording, and the history can be set to any value between **1 sec and 600 sec**.

11.5 Automatic Trigger

The automatic trigger function for the oscilloscope recorder and half period recorder can be separated enabled or disabled.

If enabled, the PQ-Box changes independently for all enabled trigger thresholds, in case of a too sensitive threshold. This prevents the recording of unnecessarily large amounts of data.

The "automatic trigger" acts for each threshold selectively and can increase all these limits (e.g. the upper and lower threshold, the step, the phase shift or the wave shape trigger)

Should a power failure occur, which leads to a continuous violation of the lower trigger threshold, the limit is automatically reset to a preset value.

Implementation of the automatic trigger:

Three timers act to decrease the sensitivity of the affected trigger level. The trigger levels for the upper threshold, lower threshold, step, phase shift and wave shape triggers are each adjusted independently.

▶ **Expansion threshold:**

This timer acts to decrease the trigger sensitivity based on an exponential function. The larger the difference between the actual trigger condition and the setting, the longer (and larger?) a decreased sensitivity is applied.

▶ **Hold threshold**

If a new trigger condition occurs that is just slightly higher than the last trigger level, that new trigger level is used as the threshold for the next 600 seconds (the 'hold threshold').

▶ **Approximation threshold**

At the end of the 'hold threshold', the 'approximation threshold' timer adjusts exponentially the threshold back to the setting value.

Using the automatic trigger function the user can ensure that the highest interference will be recorded always.



For short measurement tasks or with custom trigger thresholds, please turn the automatic trigger function always off.

Do you want to capture measurement data over a long period (> 5 days) and you do not know the exact conditions of the network? Then the auto-trigger function helps when the thresholds are set too low to not fill immediately the device memory.

11.6 Ripple control signal analysis



Ripple control

<input checked="" type="checkbox"/> Ripple control signal: ON / OFF	
Ripple-control frequency [Hz]	287
Limit [% UN]	9,00
Bandwidth filter [Hz]	5
Recorder time [sec]	60
Trigger threshold [% UN]	0,5

Ripple-control frequency [Hz]	287
-------------------------------	-----

In the ripple control signal frequency field any frequency can be entered in the range from 100 Hz to 3,750 Hz. This frequency now will be permanently recorded as a maximum value of 200ms interval in the cyclic data. If the frequency will be set smaller than 100Hz, the 3 sec. recordings for this signal stop.

Limit [% UN]	9,00
--------------	------

At this point, the limit value of the standard evaluation for the ripple control frequency can be changed.

Option ripple signal recorder (R1)

If the option “ripple signal recorder” activated in the PQ-Box, it is possible to start a high speed recorder that monitors this frequency.

You can setup the frequency of the signal, the bandwidth of the filter, the recorder time length and the trigger threshold voltage. The maximum recorder length is 210 seconds.

<input checked="" type="checkbox"/> Ripple control signal recorder ON / OFF	It is possible to enable or disable this recorder
---	---

PQ-Box with licensed/active optional “Ripple Signal Recorder” can be identified by the LCD display (6th Screen) showing “+S” after the PQ-Box 150 type.

- ▶ The ripple control recorder can generate large amounts of data and should be turned on only when specifically a disturbance in the waveform is searched.

11.7 Scheduled Operation



Scheduled Operation

Programming the PQ-Box through a time command

It is possible to start and stop the PQ-Box using a predefined time command.

Example: The PQ-Box should switch on at the 27th Dec. 2017 at 15:00 o'clock and stop at 1st Jan. 2018 at 15:00 o'clock.

☒ Scheduled operation

For technical reasons you have to set your starting time shortly before your intended start of measurement

Start

27.12.2017 14:59

End

01.01.2018 15:00

- If the start button on the PQ-Box is pressed before the measurement job, the PQ-Box starts recording immediately.
- If the stop button of the PQ-Box is pressed before the end of the measurement job, the measurement is stopped immediately.

Setting the PQ-Box date and time:

Time adjustment PQ-Box

PC - Date: 24.10.2017 PQBox - Date: 00.00.0000

PC - Time: 13:36:12 PQBox - Time: 00:00:00

Synchronize Time

☒ Auto synchronize

Synchronize Time

Synchronizes the PQ-Box time with the PC time at the moment when the button is pressed. The PQ-Box time will not hereafter be permanently shown on the PC screen.

☒ Auto-Synchronize

If this option is activated, the PC automatically synchronizes the PQ-Box as each setup is sent.

11.8 PQ-Box 50 Firmware Update




Update device


In the "Update" menu the firmware of the network analyzer can be updated or the PQ-Box can be assigned with a license code with more functions.

Sequence for a PQ-Box 50 update:

- 1) Connect the power to the PQ-Box (power supply)
- 2) Connect PQ Box with USB or TCP interface to PC
- 3) Open the Settings / Update menu in the software
- 4) Load the update file "MCU-Application" onto the device
- 5) The PQ-Box restarting automatically



11.9 PQ-Box License Update

Using the  button, with the measurement device connected, the serial number of the PQ-Box is displayed. Enter the license code in the "License Code" field by specifying the directory or using the keyboard. If the license code matches the serial number of the device, the field "Update License" is activated.

12. Data Converter


12.1 Change VT and CT ratio

With the "Data Converter" program it is possible to make corrections to an existing measurement file. If a PQ-Box is parameterized with the wrong nominal voltage or the wrong current conversion factor, this can be changed here afterwards.

- ▶ **Changing the nominal voltage, e.g. from 400 V to 20,000 V**
- ▶ **Changing the current conversion factor, e.g. from 1:1 to 1:10**




- 1) Open the measurement file to be changed with "Load"
- 2) Enter the correct voltage or current conversion factor
- 3) With "Execute", the measured data are now converted and saved to a copy of the original file. This can be identified by the label "New" in comment field 4.



12.2 Merging partial measurements into a combined measurement

Using the Data Converter-program, individual partial measurements can be merged into one combined measurement.

- 1) Open the measurement file to be changed with "Load"
- 2) Mark two or more data files
- 3) With "Combine" these measurement files will be merged and saved in a new measurement file.



13. Online Analysis: PQ-Box & PC



Using the "Online analysis" function, RMS values, oscilloscope images, harmonics, interharmonics, and current flow direction of the harmonics can be displayed online on the screen of a PC or laptop. The data displayed will be refreshed in the second intervals.

The online measurement is possible during a current measurement, before a started measurement and after a completed measurement,




All real time data screens can be started and stopped with the icons:

13.1 Online - Oscilloscope Image

All of the following images of the online measurement are shown in the "Black Magic" design

From the "Oscilloscope" page, the online oscilloscope, with 20,48kHz sampling of all measurement channels are displayed on the screen.




13.2 Online – FFT – 10kHz


With the "Spectrum" measurement function, all of the harmonics and interharmonics for voltages and currents are displayed online.

- PQ-Box 50 - DC to 10.000 Hz

There is the possibility to choose between two FFT calculation methods in the online software:



- 0 - 3.000 Hz: calculation procedure according to IEC 61000-4-30 class A (Grid synchronous FFT)
- 2.000 Hz – 10kHz: calculation procedure according to IEC 61000-4 -7 Appendix B




The following functions are available in the "right mouse" menu:

- Print: The current image is sent to the printer
- Clipboard: The spectrum is copied to the Windows clipboard
- Incl. DC: The DC components can be toggled on and off in the graphic
- incl. Fundamental oscillation: The fundamental oscillations can be toggled on and off in the graphic

Maximum values logging FFT

Using this function it is possible to hold the maximum value of the spectral lines of online FFT. (Dashed line).


With this function it is possible to determine direct in online view which maximum values of harmonics or interharmonics exists direct during one measurement period.




13.3 Online - Harmonics

From the "Harmonics" tab page, all of the current and voltage harmonics (2nd to 50th) can be displayed online. The measurement data is calculated by the measuring device in accordance with IEC61000-4-30 Class A and transferred to the PC.

Tab page – Voltage and current harmonics




Different functions are possible in the "right mouse menu" (Data export, manual scaling, split axis)



13.4 Online - Interharmonics


From the "Interharmonics" tab page, all of the current and voltage interharmonics up to 2,500 Hz can be displayed online. The measurement data is calculated by the measuring device in accordance with IEC61000-4-30 Class A following the grouping process and transferred to the PC.

Tab page - Interharmonics



Explanation of the grouping process in accordance with the IEC:

To evaluate the interharmonics in the network, subgroups are created. In each case, all of the interharmonics between two harmonics are combined into one harmonics subgroup.




13.5 Online – Direction of the Harmonics

From the "Harmonics Direction" tape page, the current flow direction of the harmonics at the measuring point is displayed. A positive value (+) represents a direction of current flow from the network to the consumer (in this example, the 5th harmonic).

If the measurement value is negative (-), a current flow from the consumer to the network is present.

$$P_2 = U_2 \cdot I_2 \cdot \cos \varphi_2$$

Note: In a network preloaded with voltage harmonics, the statement of the direction of the harmonics is not always certain. The greater the load on the network with a current harmonic from the consumer is and the less the network is preloaded with voltage harmonics, the greater the significance of this sign on the causer of harmonics in the network.




Phase angle of current harmonics:

The measured values at the bottom of the graph show the angle of the current harmonics with respect to each fundamental of the voltage.

► **Example:**


At one connections point with several consumers should be analyzed, whether the 5th harmonic will be added or subtracted. In our example customer A has 92A and customer B has 123A 5th harmonic current. Together with the phase angle of the current harmonic, it is possible to calculate the result with 55,5A.



13.6 Harmonic power and phase angle

Phase angle and power values of harmonics 2nd to 40th order number listed on the screen below.

- ▶ Phase angle of the voltage harmonic relative to fundamental of the voltage
- ▶ Phase angle of the current harmonic relative to fundamental of the voltage
- ▶ Real power harmonics (W)
- ▶ Reactive power harmonics (Var)
- ▶ Apparent power harmonics (VA)



13.7 Online Level-Time Diagram

In the "Online level-time diagram", the voltages, currents and performance can be monitored over an adjustable period (1, 3, 5 or 10 minutes).


Using the right mouse menu, the scales can be adjusted or the image copied to the clipboard.

With the "Clear Display" function, the measurement data are removed from the image.



13.8 Online - Measurement Value Details

From the "Details" tab page, the active, reactive and apparent power of the single-phase and three-phase values are also displayed online, as well as the power factor and phase angle of the fundamental oscillation of the network.



Description of power values in online "Details"

- P = real power values
- S = apparent power values
- Q = total reactive power


The total reactive power will be calculated from:

- QV = reactive power of fundamental frequency
- D = distortion power
- Qmod = modulation power
- Qu = unbalance power

$$Q_{\text{tot}, \Sigma} = \sqrt{Q_V^2 + Q_u^2 + Q_h^2 + Q_d^2 + Q_m^2}$$


13.9 Online - Phasor Diagram

Using the Phasor Diagram function, the voltages and currents are plotted graphically with their magnitude and phase angle.




13.10 Power Triangle

On the "Power Triangle" tab page, all performance values are shown in a three-dimensional graphic. It in each case a power triangle is displayed for each phase and for the overall network performance.




The graphic displays the individual power values once for the total RMS value as well as for the fundamental oscillation values.



13.11 Online Status PQ-Box

In “Online status PQ-Box” the state of the power quality analyzer can be queried via a remote connection.

- Duration of the current measurement
- Number of fault records in the current measurement
- Used memory of the device
- Free memory of the PQ-Box
- Local date and time of the device



14. Measurement Data – PQ-Box 50

14.1 Measured quantities

PQ-Box Cyclic Measurement Values

Note: The interval corresponds to the freely selectable measurement interval (1 sec up to 30 min)

For each cyclic measurement interval there are 5604 bytes of recording data. If the memory space is reserved for cyclic data f. e. to 500 MB, 91360 measuring intervals can be written until the reserved disk space is full.

If the recording interval is set to 10 minutes, this corresponds to a recording duration of 632 days.

14.2 PQ-Box Measurement Procedure / Formulas

Signal sampling:

The voltage and current inputs are filtered with an anti-aliasing filter and digitized with a 24-bit converter.

The sampling rate is at the nominal frequency

- PQ-Box 50 Expert: 20.48 k samples/s for voltage and current per channel,

The aggregation of the measurements is based on IEC61000-4-30 for Class A devices.

▶ RMS values of the voltages and currents, min. / max. values

U eff / I eff

The interval value of the voltage or current is the mean of the RMS values of the length of the selected interval.

U min / max; I min / max

Per measurement period, the highest and lowest 10 ms voltage or current RMS value is saved in addition to the average.

▶ Ripple control signal

U Ripple Control (200 ms)

Any inter-harmonics can be set in the PQ-Box 200 setup. This is displayed as the 200 ms maximum value within a measurement interval.

▶ Flicker levels P_{st} / P_{lt}

The **Short term flicker levels** P_{st} (10 min) and **Long term flicker levels** P_{lt} (2 h) are calculated for the star and delta voltages. P_{st} and P_{lt} are defined in EN 61000-4-15: 2010.


- ▶ The measuring interval of the P_{st} is set to 10 minutes fix and is independently from the free intervall.

Formula for P_{lt} calculation:

$$P_{lt} = \sqrt[3]{\frac{1}{12} \sum_{i=1}^{12} P_{st,i}^3}$$

▶ THD – PWHD – K factor

All calculations are based on a 10/12 cycle averaging interval (50 Hz = 10 cycles / 60 Hz = 12 cycles), according the formula of IEC61000-4-7 (exactly 2024 sample values will be used for calculation)



The THD calculation of voltage and current can be changed in the settings: 2 – 40th or 2 – 50th

THD voltage:

$$THD_u = \frac{\sqrt{\sum_{v=2}^{40} U_v^2}}{U_1}$$

THD current in %:

$$THD_i = \frac{\sqrt{\sum_{v=2}^{40} I_v^2}}{I_1}$$

THD(A) current in Ampere:

$$THC = \sqrt{\sum_{n=2}^{40} I_n^2}$$

PWHD - Partial Weighted Harmonic Distortion

The partial weighted THD calculates the 14th to 40th harmonics.

$$PWHD = \frac{\sqrt{\sum_{n=14}^{40} n \cdot C_n^2}}{C_1}$$

PHC - Partial Odd Harmonic Current

The PHC is calculated from the odd current harmonics $n = 21..39$.

$$PHC = \sqrt{\sum_{n=21,23}^{39} C_n^2}$$

K Factor

The values of the K-factors for phase currents are calculated from the corresponding RMS values C_n of the harmonics $n = 1..40$.

The K factor is a measure that indicates the ability of a transformer to withstand the current harmonics of a system.

Various transformer suppliers offer transformers with, for example, K factors $K=4$, $K=13$, $K=20$ and $K=30$.

Transformers are heated more by harmonic currents than 50 Hz currents.

A transformer with a higher K-factor withstands this better and is not heated as much as a transformer with a lower K factor.


The PQ-Box 200 shows the K factor for the current. Only the K values that appear at maximum power are of interest. Just as with the THD of the currents in %, the value is not relevant at very low currents.

$$K = \frac{\sum_{n=1}^{40} (n \cdot C_n)^2}{\sum_{n=1}^{40} C_n^2}$$


► Harmonics / Inter-harmonics

The determination of the harmonics and inter-harmonics interval values displayed using the methods of the IEC61000-4-30 Class A standard based on 10/12 period values.

The PQ-Box 200 recognizes for all voltage and current channels, respectively, the harmonics up to the 50th ordinal. To evaluate the inter-harmonics, harmonic subgroups are created. 50 subgroups are recorded for all current and voltage channels.



Example:



"IH1" is the first inter-harmonics group and evaluated the frequency range from 5 Hz to 45 Hz.

The harmonics for n=0...50 are calculated

Voltage harmonics (standardized, 10/12 periods):

$$|U_{n-10/12}| = \frac{\sqrt{\frac{1}{2} \cdot \sum_{k=n \cdot N-1}^{n \cdot N+1} |C_k|^2}}{U_{nom}}$$

Current harmonics:

$$|I_{n-10/12}| = \sqrt{\frac{1}{2} \cdot \sum_{k=n \cdot N-1}^{n \cdot N+1} |C_k|^2}$$

► Frequency analysis 2 kHz to 9 kHz

In the frequency analysis 2 kHz to 9 kHz respectively 200 Hz frequency bands are summarized.

The specification of each frequency is the center frequency in this 200 Hz band.

$$Y_b = \sqrt{\sum_{f=b-95 \text{ Hz}}^{b+100 \text{ Hz}} Y_{Cf}^2}$$

Example: Frequency band 8.9 kHz corresponds to all 5 Hz spectral lines from 8.805Hz to 9.000Hz

We take care of it

► **Reactive power / Reactive energy**

In the setup of the PQ Box 200 two variants of the power calculation are adjustable

a) Simplified power calculation

Reactive power without unbalanced reactive power calculation:

$$Q = \sqrt{Q_V^2 + D^2} \quad Q_{\Sigma} = Q_{L1} + Q_{L2} + Q_{L3}$$

b) Reactive power calculation according DIN40110 part 2

Reactive power calculation with unbalanced power:

$$Q_{L-10/12} = \text{Sgn}(\varphi_{L-10/12}) \cdot \sqrt{S_{L-10/12}^2 - P_{L-10/12}^2}$$

$$Q_{10/12} = \text{Sgn}(\varphi_{1-10/12}) \cdot \sqrt{S_{10/12}^2 - P_{10/12}^2}$$

Reactive energy:


"Supply reactive energy" inductive reactive energies +EQ.

$$Q_S(n) = |Q_{L-10/12}(n)| \quad \text{für : } Q_{L-10/12}(n) \geq 0$$

$$Q_S(n) = 0 \quad \text{für : } Q_{L-10/12}(n) < 0$$

"Consumer reactive energy" capacitive reactive energies -EQ.

$$Q_S(n) = |Q_{L-10/12}(n)| \quad \text{für : } Q_{L-10/12}(n) < 0$$




► Distortion reactive power - D

The distortion reactive power - also called the harmonic reactive power - describes a specific form of reactive power that is caused in single phase and three-phase systems with non-linear loads such as rectifiers in power supplies. The current harmonics in combination with the line voltage result in reactive power components, which are called the distortion reactive power.

The distortion reactive powers are calculated from the voltage and the associated distortion currents:

$$D = U \cdot \sqrt{\sum_{v=2}^{\infty} I_v^2}$$



► Power Factor PF

In electrical engineering the power factor or active power factor is calculated as the ratio of real power P to the apparent power S. The power factor can be between 0 and 1.

The ratio is expressed in the following equation:


Power Factor PF: $\lambda = P / S$

The power factor contains the sign of the real power.

Cos phi

The PQ-Box calculates the cos phi in two versions:

- cos phi – standard (red)
- cos phi – calculated in the direction of the real power (blue)



On device display and in online measurement data, the standard cos phi (version a) is shown. In the long-term measurement data both versions are available.

► **Apparent Power - S**

In the setup of the PQ Box 200 two variants of the power calculation are adjustable:

a) **Simplified power calculation**

$$S = \sqrt{P^2 + Q^2}$$

b) **Power calculation according DIN40110 part 2**

Conductor apparent power 4-wire system:

$$S_L = U_{LNrms} \cdot I_{Lrms}$$

Conductor apparent power 3-wire system:

$$S_L = U_{L0rms} \cdot I_{Lrms}$$

Collective apparent power in accordance with DIN40110:

$$S_{\Sigma} = U_{\Sigma} \cdot I_{\Sigma} \quad U_{\Sigma} = \frac{1}{2} \cdot \sqrt{U_{12rms}^2 + U_{23rms}^2 + U_{31rms}^2 + U_{1Nrms}^2 + U_{2Nrms}^2 + U_{3Nrms}^2}$$

4-wire network:

$$I_{\Sigma} = \sqrt{I_{1rms}^2 + I_{2rms}^2 + I_{3rms}^2 + I_{Nrms}^2}$$

3-wire network, $I_1 + I_2 + I_3 \neq 0$:

$$U_{\Sigma} = \frac{1}{2} \cdot \sqrt{U_{12rms}^2 + U_{23rms}^2 + U_{31rms}^2 + U_{1Erms}^2 + U_{2Erms}^2 + U_{3Erms}^2}$$

$$I_{\Sigma} = \sqrt{I_{1rms}^2 + I_{2rms}^2 + I_{3rms}^2 + I_{Erms}^2}$$

Geometric Fundamental Oscillations - Apparent Power:

$$\underline{S}_G = 3 \cdot [\underline{U}_{1_PS} \cdot \underline{I}_{1_PS}^* + \underline{U}_{1_NS} \cdot \underline{I}_{1_NS}^* + \underline{U}_{1_ZS} \cdot \underline{I}_{1_ZS}^*]$$

► Active Power - P

The sign of the active power corresponds with the flow direction of the fundamental oscillation active energy (+: supply, - : consumer).

The values of the conductor - active power are calculated from the samples of a synchronization cycle.

$$P_{L-10/12} = \frac{\sum_{n=1}^{2048} p_L(n)}{2048}$$

(200 ms values) with conductor index L = {1, 2, 3, E}

The 10 min values are calculated as linear averages.

The collective effective power is defined for 4-wire and 3-wire systems as

$$P_{\Sigma} = P_1 + P_2 + P_3$$

Fundamental oscillation - active power (line):

$$P_G = \text{Re}\{\underline{S}_G\}$$

\underline{S}_G = Geometric fundamental oscillation apparent power

P min / max (1 sec)

The highest and lowest 1 sec effective value is recorded in addition to the mean value for each measurement interval for all power values.

► Symmetric Components

The complex symmetrical components are calculated from the corresponding complex spectral components of the fundamental oscillations of the phase voltages and phase currents.

Phase voltage in a 4-wire system = Phase-to-Neutral voltage

Phase voltage in a 3-wire system = Phase-to-Ground voltage

We take care of it

Positive sequence:

$$\underline{U}_{1_PS} = \frac{1}{3} \cdot (\underline{U}_{1N-1} + \underline{a} \cdot \underline{U}_{2N-1} + \underline{a}^2 \cdot \underline{U}_{3N-1})$$

$$\underline{I}_{1_PS} = \frac{1}{3} \cdot (\underline{I}_{1-1} + \underline{a} \cdot \underline{I}_{2-1} + \underline{a}^2 \cdot \underline{I}_{3-1})$$

Negative sequence:

$$\underline{U}_{1_NS} = \frac{1}{3} \cdot (\underline{U}_{1N-1} + \underline{a}^2 \cdot \underline{U}_{2N-1} + \underline{a} \cdot \underline{U}_{3N-1})$$

$$\underline{I}_{1_NS} = \frac{1}{3} \cdot (\underline{I}_{1N-1} + \underline{a}^2 \cdot \underline{I}_{2N-1} + \underline{a} \cdot \underline{I}_{3N-1})$$

Zero sequence:

$$\underline{U}_{ZS} = \frac{1}{3} \cdot (\underline{U}_{1N-1} + \underline{U}_{2N-1} + \underline{U}_{3N-1})$$

$$\underline{I}_{ZS} = \frac{1}{3} \cdot (\underline{I}_{1N-1} + \underline{I}_{2N-1} + \underline{I}_{3N-1})$$

► UU Unbalance

The unbalanced voltages are calculated from the corresponding values of the modal positive sequence, negative sequence and zero sequence components.

For the EN50160 (events) only the voltage unbalance u_u is relevant since it corresponds to the ratio of the negative sequence to the positive sequence. The value is expressed in [%].

15. Maintenance/Cleaning


This unit is maintenance-free for customers.

Exceptions are the battery pack and micro-SD card, which can be accessed via a maintenance cover on the rear panel. The fuse in the voltage leads.


- Remove the rubber protective cover
- PQ-Box 50 open the housing cover by unscrewing the 4 screws on the back


Spare parts no.

• Replacement battery pack	570.0015
• Fuse for voltage leads; 500mA (FF) 50kA AC/DC; 600V 6,3mmx32mm	582.1058

 **DANGER!**

Danger to life due to electric shock!

 Do not open the unit.

 Maintenance of the equipment can only be carried out by A-Eberle.

For service, contact A-Eberle.

Service address:

A. Eberle GmbH & Co. KG
 Frankenstraße 160
 D-90461 Nuremberg

16. Calibration

We recommend a calibration interval of three years for the network analyzer PQ-Box 150 & 200 to maintain the accuracy of GEFOR-made-IEC61000-4-30 Class A instruments.

17. Disposal

To dispose of the device and its accessories, send all components to A-Eberle.

18. Product Warranty

- A-Eberle guarantees that this product will remain free of defects in material and workmanship for a period of three years from the date of purchase.
- For accessories like current clamps and the battery the period is one year.
- This warranty does not cover damage caused by accident, misuse or abnormal operating conditions.

To obtain service during the warranty period, please contact A-Eberle GmbH & Co KG in Nuremberg.

A. Eberle GmbH & Co. KG

Frankenstraße 160
D-90461 Nuremberg

Tel.: +49-(0)911-62 81 08-0
Fax: +49 (0) 911 / 62 81 08-99
E-Mail: info@a-eberle.de

<http://www.a-eberle.de>

No. 584.0871